

RICOH

Bizgram Asia Pte Ltd

Category	Part Number	Description
SPARE PARTS	CA04315-Z700	PULLEY
SPARE PARTS	CA04315-Z703	GEAR
SPARE PARTS	CA04315-Z704	GEAR
SPARE PARTS	CA04315-Z708	SPACER
SPARE PARTS	CA80409-0082	BEARING
SPARE PARTS	CA80409-0161	BEARING
SPARE PARTS	CA80409-0181	BEARING
SPARE PARTS	CA80409-0183	BEARING
SPARE PARTS	CA98001-8785	SCREW
SPARE PARTS	CA98010-1886	PRISM
SPARE PARTS	CA98010-2258	MICROSWITCH
SPARE PARTS	CT-EDS-1208U-KG	CLAMP
SPARE PARTS	PA02212-Y052	BEARING
SPARE PARTS	PA02212-Y117	PINION
SPARE PARTS	PA03001-Y411	BEARING
SPARE PARTS	PA03002-Y020	FOOT
SPARE PARTS	PA03209-K912	RING
SPARE PARTS	PA03209-K920	INVERTER
SPARE PARTS	PA03209-K935	AC CABLE C
SPARE PARTS	PA03209-K945	PANEL COVER C
SPARE PARTS	PA03209-Y398	HANDLE-SS
SPARE PARTS	PA03209-Y399	HANDLE-BASE-SS
SPARE PARTS	PA03237-Y205	GEAR
SPARE PARTS	PA03277-0003	PAD ASSY WHITE
SPARE PARTS	PA03277-D944	SENSOR
SPARE PARTS	PA03277-K901	POWER SUPPLY
SPARE PARTS	PA03277-Y120	TEST CHART No.42
SPARE PARTS	PA03277-Y123	TEST CHART(W)
SPARE PARTS	PA03277-Y219	IDLE GEAR
SPARE PARTS	PA03277-Y220	PLANET GEAR
SPARE PARTS	PA03277-Y351	USB PROTECTOR
SPARE PARTS	PA03277-Y519	R SHAFT
SPARE PARTS	PA03277-Y607	GRIP SPRING
SPARE PARTS	PA03289-F953	PR CABLE
SPARE PARTS	PA03289-F954	FELT
SPARE PARTS	PA03289-K910	GUIDE SHEET
SPARE PARTS	PA03289-Y021	PINCH ROLLER
SPARE PARTS	PA03289-Y048	PINCH SHAFT
SPARE PARTS	PA03289-Y120	TEST CHART
SPARE PARTS	PA03289-Y355	P ROLLER1 EH
SPARE PARTS	PA03289-Y409	W GEAR
SPARE PARTS	PA03289-Y508	ADJ PULLEY
SPARE PARTS	PA03289-Y613	F ROLLER
SPARE PARTS	PA03289-Y900	ADJ SPRING JIG
SPARE PARTS	PA03296-Y190	DISELECTRIC BRUSH
SPARE PARTS	PA03296-Y605	IDLER GEAR
SPARE PARTS	PA03296-Y812	LOCK COLLAR R
SPARE PARTS	PA03296-Y990	ADJUSTMENT SHEET
SPARE PARTS	PA03334-E955	IM HOLDER ASSY
SPARE PARTS	PA03334-F902	US SENSOR
SPARE PARTS	PA03334-F914	SENSOR EM
SPARE PARTS	PA03334-F951	HOLDER LEVER
SPARE PARTS	PA03334-F952	FPC CABLE
SPARE PARTS	PA03334-F954	FELT
SPARE PARTS	PA03334-F958	STOPPER
SPARE PARTS	PA03334-K906	US PCA
SPARE PARTS	PA03334-K961	JUNCTION PCA

SPARE PARTS	PA03334-K966	CONTROL PCA
SPARE PARTS	PA03334-Y008	LOCK ARM
SPARE PARTS	PA03334-Y030	EXIT ROLLER
SPARE PARTS	PA03334-Y035	FEED PULLEY
SPARE PARTS	PA03334-Y641	IM EXIT ROLLER
SPARE PARTS	PA03338-D816	SENSOR
SPARE PARTS	PA03338-D822	BW MOTOR
SPARE PARTS	PA03338-D826	TOP SENSOR
SPARE PARTS	PA03338-D917	SENSOR OP
SPARE PARTS	PA03338-Y011	GUIDE RAILME
SPARE PARTS	PA03338-Y014	FB BASE PLATE 2
SPARE PARTS	PA03338-Y021	CR FG PLATE
SPARE PARTS	PA03338-Y063	LED PIPE
SPARE PARTS	PA03338-Y083	FB TENSIONER
SPARE PARTS	PA03338-Y084	FB TENSIONER PIN
SPARE PARTS	PA03338-Y086	TENSION PULLEY
SPARE PARTS	PA03338-Y103	DOC GUIDE RAIL F
SPARE PARTS	PA03338-Y112	STAGE PLATE
SPARE PARTS	PA03338-Y125	HINGESTOPPER
SPARE PARTS	PA03338-Y130	D LOCK ARM L
SPARE PARTS	PA03338-Y131	D LOCK ARM R
SPARE PARTS	PA03338-Y133	D LOCK LEVER
SPARE PARTS	PA03338-Y136	D LOCK PLATE R
SPARE PARTS	PA03338-Y137	DLOC SPRING
SPARE PARTS	PA03338-Y140	STAGE PLATE S
SPARE PARTS	PA03338-Y141	STAGE SPRING
SPARE PARTS	PA03338-Y170	CR SHAFT
SPARE PARTS	PA03338-Y204	LOCK ARM F
SPARE PARTS	PA03338-Y205	LOCK ARM B
SPARE PARTS	PA03338-Y218	BEARING POM
SPARE PARTS	PA03338-Y228	CANCEL SPRING M
SPARE PARTS	PA03338-Y243	ARM ROLLER
SPARE PARTS	PA03338-Y303	DETENT LEVER
SPARE PARTS	PA03338-Y304	DETENT CUSHION
SPARE PARTS	PA03338-Y368	BASE PIN COLLAR
SPARE PARTS	PA03338-Y514	CR COVER
SPARE PARTS	PA03338-Y543	ROLLER
SPARE PARTS	PA03338-Y605	RACK
SPARE PARTS	PA03338-Y606	GUIDE SHAFT
SPARE PARTS	PA03338-Y611	BT GEAR PULLEY
SPARE PARTS	PA03338-Y612	BT COLLAR
SPARE PARTS	PA03338-Y615	BT SPRING
SPARE PARTS	PA03338-Y625	SPRING COLLAR
SPARE PARTS	PA03338-Y629	SLIDE LEVER
SPARE PARTS	PA03338-Y630	CHANGE PANEL
SPARE PARTS	PA03338-Y633	WEIGHT SPRING 2
SPARE PARTS	PA03338-Y754	RACK (BLACK)
SPARE PARTS	PA03360-Y113	BEARING
SPARE PARTS	PA03368-K026	FINGER GUIDE
SPARE PARTS	PA03368-K902	LCD
SPARE PARTS	PA03368-K903	SENSOR PCA
SPARE PARTS	PA03368-K904	SWITCH PCA
SPARE PARTS	PA03368-K907	LCD CABLE
SPARE PARTS	PA03420-K954	DOC COVER ASSY
SPARE PARTS	PA03420-K956	PANEL PCA ASSY
SPARE PARTS	PA03420-K957	DOC-COV-PIN
SPARE PARTS	PA03420-Y008	IMAGE SENSOR CARRIER
SPARE PARTS	PA03420-Y011	CONTACT PIN
SPARE PARTS	PA03420-Y016	WORM GEAR
SPARE PARTS	PA03420-Y018	IDLER PULLEY
SPARE PARTS	PA03420-Y022	TENSION SPRING
SPARE PARTS	PA03420-Y025	PULLY PLATE

SPARE PARTS	PA03420-Y027	RUBBER FOOT
SPARE PARTS	PA03420-Y032	SENSOR SPRING
SPARE PARTS	PA03420-Y105	CR-LOCK LEVER
SPARE PARTS	PA03420-Y202	CARRIER SHAFT
SPARE PARTS	PA03420-Y904	TEST CHART NO.83
SPARE PARTS	PA03450-D730	PRB FRAME UNIT
SPARE PARTS	PA03450-D776	PINCH ROLLER K
SPARE PARTS	PA03450-D816	PAD BASE ASY EH
SPARE PARTS	PA03450-D850	JUPITEREH-POW-JNT
SPARE PARTS	PA03450-D897	CCD CABLE F
SPARE PARTS	PA03450-D902	PANEL PCA
SPARE PARTS	PA03450-D906	SENSOR PCA
SPARE PARTS	PA03450-D907	ENCODER PCA 1
SPARE PARTS	PA03450-D908	ENCODER PCA 2
SPARE PARTS	PA03450-D909	JUPITER-ENC3
SPARE PARTS	PA03450-D924	PICK ROLLER UNIT EH
SPARE PARTS	PA03450-D927	CLUTCH PULLEY
SPARE PARTS	PA03450-D929	FAN ASSY
SPARE PARTS	PA03450-D930	INVERTER
SPARE PARTS	PA03450-D931	SENSOR
SPARE PARTS	PA03450-D932	SENSOR PTR ASSY
SPARE PARTS	PA03450-D933	SENSOR PTR
SPARE PARTS	PA03450-D934	SENSOR LED ASSY
SPARE PARTS	PA03450-D935	SENSOR LED
SPARE PARTS	PA03450-D936	GAS DAMPER
SPARE PARTS	PA03450-D937	LOCK-COLLAR
SPARE PARTS	PA03450-D939	LF MOTOR
SPARE PARTS	PA03450-D942	LIFT ASSY
SPARE PARTS	PA03450-D943	SUPPORTER
SPARE PARTS	PA03450-D945	BELT FEED 1
SPARE PARTS	PA03450-D946	BELT FEED 2
SPARE PARTS	PA03450-D947	BELT SEPARATION
SPARE PARTS	PA03450-D948	BELT PICK
SPARE PARTS	PA03450-D950	DIMM
SPARE PARTS	PA03450-D958	TORQUE DAMPER
SPARE PARTS	PA03450-D963	BACKGROUND UNIT, LOWER
SPARE PARTS	PA03450-D964	BACKGROUND UNIT, UPPER
SPARE PARTS	PA03450-D965	GLASS ASSY
SPARE PARTS	PA03450-D966	LAMP ASSY
SPARE PARTS	PA03450-D967	HOPPER UNIT EH
SPARE PARTS	PA03450-D968	STACKER UNIT EH
SPARE PARTS	PA03450-D969	STK SLD3 ASY EH
SPARE PARTS	PA03450-D974	EXIT SENSOR JAM
SPARE PARTS	PA03450-D975	FEED-ROLLER-K
SPARE PARTS	PA03450-D979	BRAKE PANEL PCA
SPARE PARTS	PA03450-D994	STACKER-SHEET
SPARE PARTS	PA03450-F001	BASE GUIDE 1 ASSY
SPARE PARTS	PA03450-F042	HOPPER SHAFT ASSY
SPARE PARTS	PA03450-F053	BRAKE ENCODER HOLD
SPARE PARTS	PA03450-F106	RV ROLL COV ASM
SPARE PARTS	PA03450-F123	PICK ENCODER HOLD
SPARE PARTS	PA03450-F127	SEPARATION ENCODER HOLD
SPARE PARTS	PA03450-F135	DRIVE SHAFT ASSY
SPARE PARTS	PA03450-F307	BASE GUIDE 3
SPARE PARTS	PA03450-F500	HOPPER CHANNEL ASSY
SPARE PARTS	PA03450-F581	STACKER MAGNET ASSY
SPARE PARTS	PA03450-F596	STACKER BACK ASSY
SPARE PARTS	PA03450-F650	SIDE COVER L
SPARE PARTS	PA03450-F660	SIDE COVER R
SPARE PARTS	PA03450-F780	PRF PRINT ASSY
SPARE PARTS	PA03450-F790	PRB PRINT ASSY
SPARE PARTS	PA03450-F890	CONSOLE KEY ASSY EH

SPARE PARTS	PA03450-F908	FEED MOTOR
SPARE PARTS	PA03450-F909	TABLE MOTOR
SPARE PARTS	PA03450-F910	SEPARATION MOTOR
SPARE PARTS	PA03450-F911	TORQUE ASSY
SPARE PARTS	PA03450-F912	PICK SOLENOID
SPARE PARTS	PA03450-F925	CONTROL PCA
SPARE PARTS	PA03450-F926	JUNCTION PCA
SPARE PARTS	PA03450-F928	BRAKE BASE PLATE
SPARE PARTS	PA03450-F929	SEPARATION PLATE
SPARE PARTS	PA03450-F931	HOPPER BASE
SPARE PARTS	PA03450-F932	SLIDE BASE
SPARE PARTS	PA03450-F933	BRUSH 1
SPARE PARTS	PA03450-F934	BRUSH 2
SPARE PARTS	PA03450-F935	US PCB PLATE
SPARE PARTS	PA03450-F941	MEMORY COVER
SPARE PARTS	PA03450-F942	SIDE GUIDE R
SPARE PARTS	PA03450-F943	SIDE GUIDE L
SPARE PARTS	PA03450-F944	UPPER GUIDE 4
SPARE PARTS	PA03450-F945	STACKER HOLD
SPARE PARTS	PA03450-F946	TPS-PLATE-ASSY
SPARE PARTS	PA03450-F948	UPPER HOLDER COVER EH
SPARE PARTS	PA03450-G063	BRAKE IDLER GEAR
SPARE PARTS	PA03450-G066	BRAKE IDLER GEAR(M10)
SPARE PARTS	PA03450-G070	CLUTCH ASSY
SPARE PARTS	PA03450-G205	BW MOTOR PLATE
SPARE PARTS	PA03450-G306	BASE GUIDE 2 ASSY
SPARE PARTS	PA03450-G424	LOCK ARM L2
SPARE PARTS	PA03450-G425	LOCK ARM R2
SPARE PARTS	PA03450-G427	UPPER GUIDE 3 ASSY
SPARE PARTS	PA03450-G433	COVER PLATE L
SPARE PARTS	PA03450-G435	COVER PLATE R
SPARE PARTS	PA03450-G589	INTERLOCK ASSY
SPARE PARTS	PA03450-K063	SLOT COVER
SPARE PARTS	PA03450-K064	8 FILTER
SPARE PARTS	PA03450-K350	ROLLER-ASSY1B-K
SPARE PARTS	PA03450-K351	ROLLER-ASSY2B-K
SPARE PARTS	PA03450-K352	ROLLER-ASSY3B-K
SPARE PARTS	PA03450-K353	ROLLER-ASSY4B-K
SPARE PARTS	PA03450-K421	CSL SHEET KIT
SPARE PARTS	PA03450-K560	PINCH-ASSY1B-K
SPARE PARTS	PA03450-K561	PINCH-ASSY2B-K
SPARE PARTS	PA03450-K562	PINCH-ASSY3B-K
SPARE PARTS	PA03450-K563	PINCH-ASSY4B-K
SPARE PARTS	PA03450-K950	FOAM KIT REV
SPARE PARTS	PA03450-K951	FOAM KIT FIX
SPARE PARTS	PA03450-K952	FOAM KIT BW
SPARE PARTS	PA03450-K953	FOAM KIT REF
SPARE PARTS	PA03450-K954	FOAM KIT GLASS
SPARE PARTS	PA03450-K955	FOAM KIT STK
SPARE PARTS	PA03450-K956	FOAM-KIT-SE
SPARE PARTS	PA03450-K980	UPPER-GUIDE1B-K
SPARE PARTS	PA03450-Y001	PAPER SET GUIDE
SPARE PARTS	PA03450-Y046	JAM LEVER
SPARE PARTS	PA03450-Y048	JAM CL SHAFT
SPARE PARTS	PA03450-Y054	BRAKE BRACKET HOLDER
SPARE PARTS	PA03450-Y056	BRAKE ADJ UST PLATE
SPARE PARTS	PA03450-Y057	BRAKE INSULATION SHEET
SPARE PARTS	PA03450-Y060	US PCB SHIELD
SPARE PARTS	PA03450-Y062	BRAKE BASE SHAFT
SPARE PARTS	PA03450-Y066	BRAKE SPRING
SPARE PARTS	PA03450-Y067	BRAKE SENSOR PLATE
SPARE PARTS	PA03450-Y072	CLUTCH COVER

SPARE PARTS	PA03450-Y078	SHAFT
SPARE PARTS	PA03450-Y079	UNIVERSAL JOINT
SPARE PARTS	PA03450-Y120	ENCODER FRAME
SPARE PARTS	PA03450-Y123	SLIDE GUIDE
SPARE PARTS	PA03450-Y128	ENCODER SENSOR COVER
SPARE PARTS	PA03450-Y130	SEPARATION SLIDE SHAFT
SPARE PARTS	PA03450-Y131	SEPARATION SLIDE GEAR
SPARE PARTS	PA03450-Y132	SEPARATION SLIDE SPRING
SPARE PARTS	PA03450-Y133	SEPARATION SLIDE LEVER
SPARE PARTS	PA03450-Y134	SEPARATION DRIVE GEAR
SPARE PARTS	PA03450-Y135	SEPARATION ROLLER SHAFT
SPARE PARTS	PA03450-Y139	BEARING STOPPER
SPARE PARTS	PA03450-Y140	SEPARATION SHEET
SPARE PARTS	PA03450-Y145	PICK MOTOR PLATE
SPARE PARTS	PA03450-Y148	BRK ENC COVER
SPARE PARTS	PA03450-Y175	US SENSOR PLATE
SPARE PARTS	PA03450-Y184	PICK ENCODER SHAFT
SPARE PARTS	PA03450-Y186	ENCODER FRAME PICK
SPARE PARTS	PA03450-Y188	ENCODE SENSOR COVER
SPARE PARTS	PA03450-Y189	ENCODE SENSOR COVER 2
SPARE PARTS	PA03450-Y203	REFLECTOR HOLDER
SPARE PARTS	PA03450-Y226	BW GEAR
SPARE PARTS	PA03450-Y232	SENSOR SPRING
SPARE PARTS	PA03450-Y236	SHEET-T
SPARE PARTS	PA03450-Y242	BW PLATE UPPER 2
SPARE PARTS	PA03450-Y243	BW SPRING PLATE
SPARE PARTS	PA03450-Y250	OPT BRACKET F
SPARE PARTS	PA03450-Y251	OPT PLATE SUB F
SPARE PARTS	PA03450-Y252	OPT BRACKET R
SPARE PARTS	PA03450-Y253	OPT BRACKET
SPARE PARTS	PA03450-Y274	CCD FOAM F
SPARE PARTS	PA03450-Y275	CCD FOAM R
SPARE PARTS	PA03450-Y278	SE FORM
SPARE PARTS	PA03450-Y288	BW CABLE SHEET
SPARE PARTS	PA03450-Y302	BEARING HOLDER
SPARE PARTS	PA03450-Y304	SPACER
SPARE PARTS	PA03450-Y308	BASE DAMP PLATE
SPARE PARTS	PA03450-Y314	BASE STOPPER
SPARE PARTS	PA03450-Y317	IMPRINTER COVER 1
SPARE PARTS	PA03450-Y318	UPPER LIMIT PLATE
SPARE PARTS	PA03450-Y320	IDLER PULLEY
SPARE PARTS	PA03450-Y321	SIDE PLATE 2
SPARE PARTS	PA03450-Y322	RUBBER FOOT
SPARE PARTS	PA03450-Y381	CLAMP PLATE
SPARE PARTS	PA03450-Y382	POWER PLATE
SPARE PARTS	PA03450-Y386	INSULATOR SHEET
SPARE PARTS	PA03450-Y388	USB COVER
SPARE PARTS	PA03450-Y400	BEARING HOLDER
SPARE PARTS	PA03450-Y401	FEED SPRING 1
SPARE PARTS	PA03450-Y402	FEED SPRING 2
SPARE PARTS	PA03450-Y404	FULCRUM BUSHING
SPARE PARTS	PA03450-Y407	LOCK ARM L1
SPARE PARTS	PA03450-Y408	LOCK ARM R1
SPARE PARTS	PA03450-Y410	LOCK SPRING 2
SPARE PARTS	PA03450-Y411	UPPER GUIDE 2
SPARE PARTS	PA03450-Y413	UPPER SWITCH PLATE
SPARE PARTS	PA03450-Y415	FEED HOLDER
SPARE PARTS	PA03450-Y416	FEED SPRING 3
SPARE PARTS	PA03450-Y417	FULCRUM SHAFT
SPARE PARTS	PA03450-Y419	LOCK SPRING 1
SPARE PARTS	PA03450-Y421	LOCK SHAFT
SPARE PARTS	PA03450-Y440	REV SE COVER

SPARE PARTS	PA03450-Y475	PAPER STOPPER 1
SPARE PARTS	PA03450-Y476	PAPER STOPPER 2
SPARE PARTS	PA03450-Y477	GUIDE FOAM
SPARE PARTS	PA03450-Y478	GUIDE SHEET1
SPARE PARTS	PA03450-Y479	PAPER STOPPER 3
SPARE PARTS	PA03450-Y501	HOPPER COVER
SPARE PARTS	PA03450-Y510	GUIDE ANGLE R
SPARE PARTS	PA03450-Y511	GUIDE ANGLE L
SPARE PARTS	PA03450-Y513	GUIDE SPRING L
SPARE PARTS	PA03450-Y514	GUIDE SPRING R
SPARE PARTS	PA03450-Y520	GEAR
SPARE PARTS	PA03450-Y521	DAMPER GEAR
SPARE PARTS	PA03450-Y522	DAMPER HOLD PLATE
SPARE PARTS	PA03450-Y523	HOPPER DOWN SPRING
SPARE PARTS	PA03450-Y524	DETENT LEVER
SPARE PARTS	PA03450-Y526	DETENT FOAM
SPARE PARTS	PA03450-Y530	PIN
SPARE PARTS	PA03450-Y533	STACKER ANGLE L
SPARE PARTS	PA03450-Y534	STACKER ANGLE R
SPARE PARTS	PA03450-Y541	SLIDE COVER
SPARE PARTS	PA03450-Y542	SLIDE SPRING
SPARE PARTS	PA03450-Y555	STACKER ANGLE SPRING
SPARE PARTS	PA03450-Y559	STACKER SLIDER
SPARE PARTS	PA03450-Y561	STACKER BASE
SPARE PARTS	PA03450-Y565	STACKER UNLOCK
SPARE PARTS	PA03450-Y566	STACKER HOLD STOPPER
SPARE PARTS	PA03450-Y569	STACKER SHAFT
SPARE PARTS	PA03450-Y593	STACKER BASE PLATE
SPARE PARTS	PA03450-Y595	STACKER EXTENSION HOLDER
SPARE PARTS	PA03450-Y598	STACKER LOCK HOLDER
SPARE PARTS	PA03450-Y611	CONSOLE CASE
SPARE PARTS	PA03450-Y612	CONSOLE CLEAR COVER
SPARE PARTS	PA03450-Y615	CONSOLE FG PLATE
SPARE PARTS	PA03450-Y616	CONSOLE LED GUIDE 1
SPARE PARTS	PA03450-Y661	TOP COVER
SPARE PARTS	PA03450-Y671	TOP COVER DOOR
SPARE PARTS	PA03450-Y691	SIDE COVER PLATE R
SPARE PARTS	PA03450-Y692	SIDE COVER PLATE L
SPARE PARTS	PA03450-Y693	SPACE PLATE R
SPARE PARTS	PA03450-Y694	SPACE PLATE L
SPARE PARTS	PA03450-Y700	FELT PLATE
SPARE PARTS	PA03450-Y701	FELT
SPARE PARTS	PA03450-Y704	IMP-LEVER
SPARE PARTS	PA03450-Y714	PAPER GUIDE
SPARE PARTS	PA03450-Y831	GRIP EH
SPARE PARTS	PA03450-Y832	GUIDE LEVER EH
SPARE PARTS	PA03450-Y833	EXTENSION EH
SPARE PARTS	PA03450-Y845	STACKER EXTENSION 2 EH
SPARE PARTS	PA03450-Y998	P-STOPPER3-JIG
SPARE PARTS	PA03484-K905	US SENSOR RV
SPARE PARTS	PA03484-Y078	PICK BEARING
SPARE PARTS	PA03540-D941	BASE UNIT
SPARE PARTS	PA03540-D955	BASE UNIT L
SPARE PARTS	PA03540-D961	UPPER UNIT
SPARE PARTS	PA03540-D967	UPPER UNIT C
SPARE PARTS	PA03540-D969	UPPER UNIT T
SPARE PARTS	PA03540-D979	UPPER UNIT T
SPARE PARTS	PA03540-D985	UPPER UNIT LA25
SPARE PARTS	PA03540-D987	UPPER UNIT LC
SPARE PARTS	PA03540-D995	UPPER UNIT LA25
SPARE PARTS	PA03540-D997	UPPER UNIT LC
SPARE PARTS	PA03540-E909	GUIDE P ASSY L

SPARE PARTS	PA03540-E941	BASE ASSY
SPARE PARTS	PA03540-E970	IM PINCH ASSY3
SPARE PARTS	PA03540-E971	IM HOLDER ASSY3
SPARE PARTS	PA03540-F631	SWITCH ASSY
SPARE PARTS	PA03540-F907	PICK SHAFT ASSY
SPARE PARTS	PA03540-F909	FB MOTOR ASSY
SPARE PARTS	PA03540-F920	LF MOTOR
SPARE PARTS	PA03540-F921	IM LOCK LEVER
SPARE PARTS	PA03540-F922	IM HOLD LEVER3
SPARE PARTS	PA03540-G070	EXTEND ASSY
SPARE PARTS	PA03540-K901	CONTROL PCA
SPARE PARTS	PA03540-K906	SENSOR EMP
SPARE PARTS	PA03540-Y010	LOCK ARM
SPARE PARTS	PA03540-Y020	BRAKE GEAR
SPARE PARTS	PA03540-Y021	BR IDLE GEAR
SPARE PARTS	PA03540-Y022	BR REV GEAR1
SPARE PARTS	PA03540-Y024	BR REDUCE GEAR
SPARE PARTS	PA03540-Y101	PICK GEAR
SPARE PARTS	PA03540-Y109	SG GEAR(M10)
SPARE PARTS	PA03540-Y122	P GEAR1
SPARE PARTS	PA03540-Y185	HK RING L3
SPARE PARTS	PA03540-Y341	CR STOPPER
SPARE PARTS	PA03540-Y345	CR STOPPER
SPARE PARTS	PA03540-Y370	CR SHAFT
SPARE PARTS	PA03540-Y441	DOC JOINT
SPARE PARTS	PA03540-Y445	DOC JOINT
SPARE PARTS	PA03540-Y611	TOP COVER LID
SPARE PARTS	PA03540-Y615	TOP COVER LID
SPARE PARTS	PA03540-Y650	LED PIPE
SPARE PARTS	PA03540-Y651	FILTER
SPARE PARTS	PA03540-Y675	FX COVER LID R
SPARE PARTS	PA03540-Y685	FX COVER LID L
SPARE PARTS	PA03540-Y766	PAPER GUIDE3
SPARE PARTS	PA03540-Y776	IM L3 E ROLLER
SPARE PARTS	PA03540-Y810	PIC JIG SPRING
SPARE PARTS	PA03541-E901	CIS UNIT F
SPARE PARTS	PA03541-E911	CIS UNIT B
SPARE PARTS	PA03541-F926	GUIDE P ASSY
SPARE PARTS	PA03541-K906	MOTOR
SPARE PARTS	PA03541-K911	HK RING
SPARE PARTS	PA03541-K918	JOINT PCA
SPARE PARTS	PA03541-K926	AC ADAPTER
SPARE PARTS	PA03541-Y001	FIXED FRAME
SPARE PARTS	PA03541-Y016	CLUTCH
SPARE PARTS	PA03541-Y017	CLUTCH GEAR
SPARE PARTS	PA03541-Y019	PULLEY GEAR
SPARE PARTS	PA03541-Y020	FEED GEAR
SPARE PARTS	PA03541-Y021	FEED PULLEY
SPARE PARTS	PA03541-Y022	REDUCTION GEAR 1
SPARE PARTS	PA03541-Y023	REDUCTION GEAR 2
SPARE PARTS	PA03541-Y024	TENSION PULLEY
SPARE PARTS	PA03541-Y028	CHUTER SW
SPARE PARTS	PA03541-Y031	SW SPRING
SPARE PARTS	PA03541-Y041	FEED ROLLER
SPARE PARTS	PA03541-Y042	EXIT ROLLER
SPARE PARTS	PA03541-Y101	REVOLVE FRAME
SPARE PARTS	PA03541-Y103	PINCH ROLLER
SPARE PARTS	PA03541-Y105	FEED SPRING
SPARE PARTS	PA03541-Y106	EXIT SPRING
SPARE PARTS	PA03541-Y112	PAD PLATE 1
SPARE PARTS	PA03541-Y113	PAD PLATE 2
SPARE PARTS	PA03541-Y118	EMP ARM2

SPARE PARTS	PA03541-Y128	PAD SPRING
SPARE PARTS	PA03541-Y145	EMP SPRING
SPARE PARTS	PA03541-Y146	EMP ARM
SPARE PARTS	PA03541-Y501	SPRING COVER
SPARE PARTS	PA03575-D650	BW ASSIST RV P
SPARE PARTS	PA03575-D748	JUNO-CTL
SPARE PARTS	PA03575-D751	STACKER-UNIT
SPARE PARTS	PA03575-D752	JUNO-CSL
SPARE PARTS	PA03575-D754	JUNO-CTL
SPARE PARTS	PA03575-D755	FR1-DRIVE-UNIT
SPARE PARTS	PA03575-D761	JUNO-CSL
SPARE PARTS	PA03575-D763	JUNO-CSL
SPARE PARTS	PA03575-D779	RV-COVER-L
SPARE PARTS	PA03575-D796	PACKAGE ASSY
SPARE PARTS	PA03575-D798	RV-COVER-L
SPARE PARTS	PA03575-D806	EX-GUIDE-T ASSY
SPARE PARTS	PA03575-D807	FIX-GUID-1 ASSY
SPARE PARTS	PA03575-D808	FIX-GUID-3 ASSY
SPARE PARTS	PA03575-D809	RV-GUIDE-2 ASSY
SPARE PARTS	PA03575-D811	JUNO-ENC-R
SPARE PARTS	PA03575-D812	JUNO-ENC-L
SPARE PARTS	PA03575-D842	EXIT MOTOR KIT
SPARE PARTS	PA03575-D843	PRISM SE KIT
SPARE PARTS	PA03575-D849	STK-SUP-ASSY
SPARE PARTS	PA03575-D870	CLUTCH UNIT
SPARE PARTS	PA03575-D871	B BRK UNIT
SPARE PARTS	PA03575-D872	DAMPER ASSY L
SPARE PARTS	PA03575-D873	GUIDE SEP
SPARE PARTS	PA03575-D874	HB PAD
SPARE PARTS	PA03575-D875	BW-UNIT-FIX
SPARE PARTS	PA03575-D876	BW-UNIT-RV
SPARE PARTS	PA03575-D879	RV ROLLER 3
SPARE PARTS	PA03575-D881	RV ROLLER 1
SPARE PARTS	PA03575-D882	RV ROLLER 2
SPARE PARTS	PA03575-D887	LOCK LEVER
SPARE PARTS	PA03575-D888	CLUTCH PULLEY
SPARE PARTS	PA03575-D892	FEED ROLLER 2
SPARE PARTS	PA03575-D893	FEED ROLLER 3
SPARE PARTS	PA03575-D894	FEED ROLLER 4
SPARE PARTS	PA03575-D895	FEED ROLLER 5
SPARE PARTS	PA03575-D896	FEED ROLLER 6
SPARE PARTS	PA03575-D897	EXIT ROLLER 1
SPARE PARTS	PA03575-D898	EXIT ROLLER 2
SPARE PARTS	PA03575-D909	CCD CABLE FIX
SPARE PARTS	PA03575-D911	JUNO MD
SPARE PARTS	PA03575-D913	JUNO SW
SPARE PARTS	PA03575-D915	DIMM
SPARE PARTS	PA03575-D919	STK-SUP-UNIT
SPARE PARTS	PA03575-D920	POWER SUPPLY
SPARE PARTS	PA03575-D921	FAN
SPARE PARTS	PA03575-D925	JUNO US FX
SPARE PARTS	PA03575-D926	PRISM SENSOR
SPARE PARTS	PA03575-D927	PHOTO SENSOR
SPARE PARTS	PA03575-D928	EMPTY SENSOR
SPARE PARTS	PA03575-D929	JUNO US RV
SPARE PARTS	PA03575-D930	OPT UNIT
SPARE PARTS	PA03575-D932	LED UNIT FX
SPARE PARTS	PA03575-D933	LED UNIT RV
SPARE PARTS	PA03575-D934	LED GLASS FX
SPARE PARTS	PA03575-D935	LED GLASS RV
SPARE PARTS	PA03575-D936	SENSOR
SPARE PARTS	PA03575-D938	SEP BRUSH

SPARE PARTS	PA03575-D939	EXIT BRUSH
SPARE PARTS	PA03575-D940	HOPPER UNIT
SPARE PARTS	PA03575-D941	STACKER UNIT
SPARE PARTS	PA03575-D942	STK STOPPER S
SPARE PARTS	PA03575-D943	STK STOPPER L
SPARE PARTS	PA03575-D945	GAS DAMPER
SPARE PARTS	PA03575-D949	LOCK ARM
SPARE PARTS	PA03575-D951	ASSIST ROLLER
SPARE PARTS	PA03575-D959	STK UNDER SHEET
SPARE PARTS	PA03575-D960	FEED MOT UNIT
SPARE PARTS	PA03575-D961	FEED MOT UNIT2
SPARE PARTS	PA03575-D962	BW MOTER UNIT
SPARE PARTS	PA03575-D963	LU MOTOR UNIT
SPARE PARTS	PA03575-D965	PIC MOTOR UNIT
SPARE PARTS	PA03575-D966	FEED BELT 1
SPARE PARTS	PA03575-D967	FEED BELT 2
SPARE PARTS	PA03575-D968	EXIT BELT 1
SPARE PARTS	PA03575-D969	EXIT BELT 2
SPARE PARTS	PA03575-D970	PIC ROLLER UNIT
SPARE PARTS	PA03575-D972	BRAKE UNIT
SPARE PARTS	PA03575-D973	FX COVER L
SPARE PARTS	PA03575-D974	FX COVER R
SPARE PARTS	PA03575-D976	RV COVER R
SPARE PARTS	PA03575-D977	STK UNDER COVER
SPARE PARTS	PA03575-D978	TOP COVER
SPARE PARTS	PA03575-D979	TOP COVER IMP
SPARE PARTS	PA03575-D980	CONTROL PCA
SPARE PARTS	PA03575-D983	HOLDER UNIT
SPARE PARTS	PA03575-D985	FELT
SPARE PARTS	PA03575-D986	CSL SHEET ENG
SPARE PARTS	PA03575-D989	CCD CABLE RV
SPARE PARTS	PA03575-D990	ADJ CHART KIT
SPARE PARTS	PA03575-D991	CSL CABLE
SPARE PARTS	PA03575-D992	USB CABLE
SPARE PARTS	PA03575-D994	LATCH
SPARE PARTS	PA03575-D995	BRAKE CHECK JIG
SPARE PARTS	PA03575-E130	OPT COVER ASSY
SPARE PARTS	PA03575-E145	STK SHAFT ASSY
SPARE PARTS	PA03575-F020	HP CHANEL ASSY
SPARE PARTS	PA03575-F030	TENSIONASSY
SPARE PARTS	PA03575-F336	GUIDE BR ASSY
SPARE PARTS	PA03575-F350	PIC FRAME UNIT
SPARE PARTS	PA03575-F354	PIC ENC ARM R
SPARE PARTS	PA03575-F355	PIC ENC ARM L
SPARE PARTS	PA03575-F401	KEYTOP ASSY
SPARE PARTS	PA03575-F411	POW-KEYTOP-ASSY(M10)
SPARE PARTS	PA03575-F501	HOP GUIDE L ASY
SPARE PARTS	PA03575-F502	HOP GUIDE R ASY
SPARE PARTS	PA03575-G001	LOCK PLATE ASSY
SPARE PARTS	PA03575-G130	P-ROLLER-ASSY
SPARE PARTS	PA03575-G450	BACK PANEL ASSY
SPARE PARTS	PA03575-G451	BACK-PANEL-ASSY
SPARE PARTS	PA03575-G738	FIX-GUIDE-2
SPARE PARTS	PA03575-K330	BRK GEAR UNIT
SPARE PARTS	PA03575-K331	BRK GEAR P UNIT
SPARE PARTS	PA03575-Y008	CCD FG SPRING
SPARE PARTS	PA03575-Y015	RACK HP
SPARE PARTS	PA03575-Y018	LU SHAFT
SPARE PARTS	PA03575-Y019	LU GEAR L
SPARE PARTS	PA03575-Y020	LU GEAR R
SPARE PARTS	PA03575-Y021	LU GEAR B
SPARE PARTS	PA03575-Y025	FEED PULLEY

SPARE PARTS	PA03575-Y038	SCREW PLATE
SPARE PARTS	PA03575-Y039	OPT HOLD PLATE
SPARE PARTS	PA03575-Y041	HOPPER FG PLATE
SPARE PARTS	PA03575-Y046	FELT-PLATE
SPARE PARTS	PA03575-Y048	MOTOR PULLEY
SPARE PARTS	PA03575-Y053	EMP PLATE
SPARE PARTS	PA03575-Y054	HP RUBBER
SPARE PARTS	PA03575-Y060	BP FG PLATE
SPARE PARTS	PA03575-Y061	GEAR STOPPER L
SPARE PARTS	PA03575-Y063	ROLLER HOLD PLT
SPARE PARTS	PA03575-Y066	LOCK GUARD PLT
SPARE PARTS	PA03575-Y068	TENSION SPRING
SPARE PARTS	PA03575-Y077	FRI-FG-SHEET
SPARE PARTS	PA03575-Y097	GEAR-STOPPER-R
SPARE PARTS	PA03575-Y120	FEED HOLDER
SPARE PARTS	PA03575-Y121	BEARING HOLDER2
SPARE PARTS	PA03575-Y128	LOCK SPRING
SPARE PARTS	PA03575-Y133	LOCK SPRING R
SPARE PARTS	PA03575-Y139	CSL FG SPRING
SPARE PARTS	PA03575-Y140	LOCK PLATE
SPARE PARTS	PA03575-Y141	STK SE PLATE
SPARE PARTS	PA03575-Y142	STK GUIDE
SPARE PARTS	PA03575-Y144	STK GEAR
SPARE PARTS	PA03575-Y148	RV BW SPRING
SPARE PARTS	PA03575-Y158	RV COV R PLT
SPARE PARTS	PA03575-Y168	EXIT SPRING
SPARE PARTS	PA03575-Y169	RV CABLE PLATE
SPARE PARTS	PA03575-Y178	EXIT FIX PLATE
SPARE PARTS	PA03575-Y185	EX LOCK SHAFT
SPARE PARTS	PA03575-Y186	EX LOCK LEVER
SPARE PARTS	PA03575-Y187	EX LOCK SPRING
SPARE PARTS	PA03575-Y188	EX ASSIST PLATE
SPARE PARTS	PA03575-Y189	EX MOTOR COVER
SPARE PARTS	PA03575-Y192	EX-DAMPER-SHEET
SPARE PARTS	PA03575-Y194	PINCH SHAFT
SPARE PARTS	PA03575-Y230	D FORM REF FX
SPARE PARTS	PA03575-Y231	D FORM SIDE FX
SPARE PARTS	PA03575-Y232	D FORM G3 FX
SPARE PARTS	PA03575-Y283	BW PLATE REV
SPARE PARTS	PA03575-Y284	GLASS FG BW
SPARE PARTS	PA03575-Y322	TL GEAR SPACER
SPARE PARTS	PA03575-Y332	BRK REV SHAFT
SPARE PARTS	PA03575-Y342	BRK ADJ PLATE
SPARE PARTS	PA03575-Y350	PIC BASE SHAFT
SPARE PARTS	PA03575-Y351	PIC ENC SHAFT
SPARE PARTS	PA03575-Y359	PIC IDLE GEAR1
SPARE PARTS	PA03575-Y366	PIC TEN SPRING
SPARE PARTS	PA03575-Y367	SEP SHAFT HOLD
SPARE PARTS	PA03575-Y371	PIC BASE FRAME
SPARE PARTS	PA03575-Y380	PIC LEVER
SPARE PARTS	PA03575-Y391	STP SE ARM1
SPARE PARTS	PA03575-Y392	STP SE ARM2
SPARE PARTS	PA03575-Y393	STP ARM HOLD
SPARE PARTS	PA03575-Y395	STP SPRING
SPARE PARTS	PA03575-Y401	FG PLATE TOP
SPARE PARTS	PA03575-Y402	CHECK LED PIPE
SPARE PARTS	PA03575-Y407	LCD COVER
SPARE PARTS	PA03575-Y408	CLEAR COVER
SPARE PARTS	PA03575-Y416	BRK-SPRING
SPARE PARTS	PA03575-Y431	SEP-REM-BRUSH
SPARE PARTS	PA03575-Y440	CT SHIELD PLT1
SPARE PARTS	PA03575-Y441	CT SHIELD PLT2

SPARE PARTS	PA03575-Y462	BRK ENC
SPARE PARTS	PA03575-Y475	SENSOR PLATE
SPARE PARTS	PA03575-Y477	HB COVER
SPARE PARTS	PA03575-Y490	TL WGEAR
SPARE PARTS	PA03575-Y510	GRIP L
SPARE PARTS	PA03575-Y513	ABSORBER CAP
SPARE PARTS	PA03575-Y551	STK-GUIDE-L
SPARE PARTS	PA03575-Y552	STK-GUIDE-R
SPARE PARTS	PA03575-Y560	STK-EXT2
SPARE PARTS	PA03575-Y570	STK-EXT3
SPARE PARTS	PA03575-Y575	STACKER EXTENSION SLIDER
SPARE PARTS	PA03575-Y611	BK PLT BC
SPARE PARTS	PA03575-Y647	SEP-REDU-PULLEY
SPARE PARTS	PA03575-Y654	RV SIDE COVER L
SPARE PARTS	PA03575-Y655	RV SIDE COVER R
SPARE PARTS	PA03575-Y685	IMP-GUIDE-SHEET(M10)
SPARE PARTS	PA03575-Y687	IM T SE FORM
SPARE PARTS	PA03575-Y695	RUBBER FOOT
SPARE PARTS	PA03575-Y703	IM-HOLD-LEVER
SPARE PARTS	PA03575-Y722	BACK FOOT L
SPARE PARTS	PA03575-Y723	BACK FOOT R
SPARE PARTS	PA03575-Y724	BACK FOOT C
SPARE PARTS	PA03575-Y726	PAPER-FG-BRUSH
SPARE PARTS	PA03575-Y770	LOCK-SHAFT
SPARE PARTS	PA03575-Y781	US-SHIELD
SPARE PARTS	PA03575-Y784	TPS-PLATE
SPARE PARTS	PA03575-Y786	FG-PLATE-BACK
SPARE PARTS	PA03576-D816	CUSHION
SPARE PARTS	PA03576-D980	ADF UNIT
SPARE PARTS	PA03576-Y018	SCREW COVER
SPARE PARTS	PA03576-Y019	CR STOPPER ME2
SPARE PARTS	PA03576-Y117	GUIDE SHAFT
SPARE PARTS	PA03576-Y323	ADF CABLE GUIDE
SPARE PARTS	PA03586-K982	TORQUE DUMPER
SPARE PARTS	PA03595-K920	USB-CABLE-UK
SPARE PARTS	PA03595-K951	CONTROL PCA
SPARE PARTS	PA03595-K952	IMG SENSOR ASSY
SPARE PARTS	PA03595-K953	DRIVE ASSY
SPARE PARTS	PA03595-K960	TOP COVER ASSY
SPARE PARTS	PA03595-K970	AC ADAPTER
SPARE PARTS	PA03595-Y030	GEAR-BOX2
SPARE PARTS	PA03595-Y031	DRIVE-PULLEY2
SPARE PARTS	PA03603-F003	CIS CABLE FIX
SPARE PARTS	PA03603-F921	SIDE COVER R ASSY
SPARE PARTS	PA03603-F931	CHUTER ASSY
SPARE PARTS	PA03603-F938	CHUTER ASSY
SPARE PARTS	PA03603-F949	GUIDE A ASSY
SPARE PARTS	PA03603-F951	LID ASSY
SPARE PARTS	PA03603-F961	BASE COVER ASSY
SPARE PARTS	PA03603-F971	PICK SHAFT UNIT
SPARE PARTS	PA03603-K771	PACKAGE
SPARE PARTS	PA03603-K931	FRONT COVER
SPARE PARTS	PA03603-K948	S1300LA-CT
SPARE PARTS	PA03603-K956	SIDE COVER L
SPARE PARTS	PA03603-K961	TOP COVER
SPARE PARTS	PA03603-K966	S1300 OP
SPARE PARTS	PA03603-Y051	CLUTCH SPRING
SPARE PARTS	PA03603-Y161	COVER DISP S
SPARE PARTS	PA03603-Y171	COVER DISP L
SPARE PARTS	PA03603-Y400	LID SHEET
SPARE PARTS	PA03603-Y401	LID SPRING
SPARE PARTS	PA03603-Y501	AC LABEL

SPARE PARTS	PA03607-D960	ADJUSTMENT SHEET
SPARE PARTS	PA03607-K990	ADJ SPRING 2
SPARE PARTS	PA03609-D982	LCD UNIT
SPARE PARTS	PA03609-E968	GUIDE A
SPARE PARTS	PA03609-K730	SO DIMM
SPARE PARTS	PA03609-K991	CONTOROL PCA
SPARE PARTS	PA03609-Y030	STACKER BASE
SPARE PARTS	PA03610-F003	FEED GEAR ASSY
SPARE PARTS	PA03610-F371	BUTTON ASSY
SPARE PARTS	PA03610-K952	S1100I CT
SPARE PARTS	PA03610-K961	S1100 OP
SPARE PARTS	PA03610-K965	FIX-SUB-ASSY
SPARE PARTS	PA03610-Y002	BEARING
SPARE PARTS	PA03610-Y005	REDUCTION GEAR1
SPARE PARTS	PA03610-Y006	REDUCTION GEAR2
SPARE PARTS	PA03610-Y011	FEED PULLEY
SPARE PARTS	PA03610-Y012	EXIT FLANGE
SPARE PARTS	PA03610-Y015	BEARING2
SPARE PARTS	PA03610-Y018	FEED STOPPER
SPARE PARTS	PA03610-Y021	CHUTER SW
SPARE PARTS	PA03610-Y022	SW SPRING
SPARE PARTS	PA03610-Y030	FEED ROLLER
SPARE PARTS	PA03610-Y031	EMP ARM
SPARE PARTS	PA03610-Y032	EMP SPRING
SPARE PARTS	PA03610-Y033	LOCK-ARM
SPARE PARTS	PA03610-Y035	LOCK-SPRING
SPARE PARTS	PA03610-Y045	RUBBER FOOT
SPARE PARTS	PA03610-Y050	CHUTER LOCK L
SPARE PARTS	PA03610-Y051	CHUTER LOCK R
SPARE PARTS	PA03610-Y111	PINCH-SPRING
SPARE PARTS	PA03610-Y121	CIS-SPRING
SPARE PARTS	PA03610-Y181	CIS DUST SHEET
SPARE PARTS	PA03610-Y311	SIDE COVER L
SPARE PARTS	PA03610-Y325	SIDE-COVER-R(M10)(H
SPARE PARTS	PA03610-Y405	TOP COVER
SPARE PARTS	PA03610-Y892	TEST CHART NO92
SPARE PARTS	PA03610-Y898	TEST CHART NO98
SPARE PARTS	PA03610-Y903	TEST CHART NO103
SPARE PARTS	PA03630-D962	UPPER UNIT AL
SPARE PARTS	PA03630-E914	STACKER UNIT
SPARE PARTS	PA03630-E941	BASE ASSY
SPARE PARTS	PA03630-F901	BW MOTOR
SPARE PARTS	PA03630-K906	SENSOR EMP
SPARE PARTS	PA03630-K990	ADJ CHART KIT2
SPARE PARTS	PA03630-Y080	FEED PULLEY2
SPARE PARTS	PA03630-Y137	TOP COVER LID
SPARE PARTS	PA03630-Y225	EMPTY ARM
SPARE PARTS	PA03630-Y571	SWITCH ASSY
SPARE PARTS	PA03630-Y890	TEST CHART W2S
SPARE PARTS	PA03641-D965	MECHA-UNIT
SPARE PARTS	PA03641-D967	MECHA-UNIT
SPARE PARTS	PA03641-F204	FOOT-COV-ASSY(M10)(H
SPARE PARTS	PA03641-F951	EXTENDER
SPARE PARTS	PA03641-F961	OPT-COVER-ASSY
SPARE PARTS	PA03641-K351	PACKAGE
SPARE PARTS	PA03641-K391	PACKAGE
SPARE PARTS	PA03641-K920	USB-CABLE-UK
SPARE PARTS	PA03641-K950	CONTROL-PCA
SPARE PARTS	PA03641-K951	SWITCH-PCA
SPARE PARTS	PA03641-K952	JNT-PCA
SPARE PARTS	PA03641-K953	IR-LED-PCA
SPARE PARTS	PA03641-K961	HEAD-COVER

SPARE PARTS	PA03641-K962	NECK-COVER-LID
SPARE PARTS	PA03641-K963	PILLAR-COVER
SPARE PARTS	PA03641-K964	NECK-COVER
SPARE PARTS	PA03641-Y331	OPT-COVER
SPARE PARTS	PA03643-D951	FIXED UNIT
SPARE PARTS	PA03643-D984	PACKAGE
SPARE PARTS	PA03643-F931	CHUTER ASSY
SPARE PARTS	PA03643-K921	S13EH-JNT
SPARE PARTS	PA03643-K931	S13EH-OP
SPARE PARTS	PA03643-K941	S13EH-CT
SPARE PARTS	PA03643-K950	USB-CABLE-P-UK
SPARE PARTS	PA03643-K951	USB-CABLE-UK
SPARE PARTS	PA03656-D894	TOP-COVER-ASSY
SPARE PARTS	PA03656-D972	FIXED-UNIT
SPARE PARTS	PA03656-D997	REVOLVE-UNIT
SPARE PARTS	PA03656-E902	FIX-SUB-UNIT
SPARE PARTS	PA03656-E912	CIS-UNIT-B
SPARE PARTS	PA03656-E922	CIS-UNIT-F
SPARE PARTS	PA03656-E932	SG-ASSY
SPARE PARTS	PA03656-E942	STACKER-ASSY
SPARE PARTS	PA03656-E952	CHUTE-ASSY
SPARE PARTS	PA03656-E956	BR-SHAFT-ASSY
SPARE PARTS	PA03656-E958	BR-ROLLER-ASSY
SPARE PARTS	PA03656-E960	MOTOR-UNIT
SPARE PARTS	PA03656-E962	GUIDE-A
SPARE PARTS	PA03656-E972	LIDCOV-ASSY
SPARE PARTS	PA03656-E976	PICK-ROLLER-ASY
SPARE PARTS	PA03656-E982	GUIDE-P-ASSY
SPARE PARTS	PA03656-E987	CONTROL-PCA
SPARE PARTS	PA03656-E991	GUIDE-R-ASSY
SPARE PARTS	PA03656-F361	CHUT-EXT-ASSY
SPARE PARTS	PA03656-F401	STK-SUB-ASSY
SPARE PARTS	PA03656-F431	STK-EXT1-C-ASY
SPARE PARTS	PA03656-F451	STK-EXT-ASSY
SPARE PARTS	PA03656-K031	PACKAGE
SPARE PARTS	PA03656-K371	PACKAGE(M10)(H
SPARE PARTS	PA03656-K421	PACKAGE
SPARE PARTS	PA03656-K941	HK-RING
SPARE PARTS	PA03656-K944	PUSH-SWITCH
SPARE PARTS	PA03656-K945	SWITCH
SPARE PARTS	PA03656-K949	AC-ADAPTER
SPARE PARTS	PA03656-K961	USB-CABLE-UK
SPARE PARTS	PA03656-K965	SWITCH
SPARE PARTS	PA03656-K966	US-SENSOR-F
SPARE PARTS	PA03656-K969	USB-CABLE
SPARE PARTS	PA03656-K973	PANEL-PCA
SPARE PARTS	PA03656-K975	FEED-ROLLER
SPARE PARTS	PA03656-K976	EXIT-ROLLER
SPARE PARTS	PA03656-K979	SENSOR2
SPARE PARTS	PA03656-K985	STACKER-EXTEND
SPARE PARTS	PA03656-K988	DIFFUSER
SPARE PARTS	PA03656-Y001	FIXED-FRAME
SPARE PARTS	PA03656-Y002	FIXED-FRAME
SPARE PARTS	PA03656-Y018	FEED-GEAR
SPARE PARTS	PA03656-Y020	FEED-PULLEY
SPARE PARTS	PA03656-Y021	REDU-PULLEY
SPARE PARTS	PA03656-Y023	REDU-GEAR
SPARE PARTS	PA03656-Y024	IDLE-GEAR1
SPARE PARTS	PA03656-Y025	IDLE-GEAR2
SPARE PARTS	PA03656-Y027	IDLE-PULLEY1
SPARE PARTS	PA03656-Y034	IDLE-GEAR3
SPARE PARTS	PA03656-Y036	SG-SPRING

SPARE PARTS	PA03656-Y052	US-FG-PLATE
SPARE PARTS	PA03656-Y053	FG-PLATE1
SPARE PARTS	PA03656-Y054	FG-PLATE2
SPARE PARTS	PA03656-Y055	MOTOR-FG-PLATE
SPARE PARTS	PA03656-Y056	USB-FG-PLATE
SPARE PARTS	PA03656-Y100	REV-FRAME
SPARE PARTS	PA03656-Y106	BEARING-POM
SPARE PARTS	PA03656-Y107	TOP-ARM
SPARE PARTS	PA03656-Y108	BRAKE-GEAR
SPARE PARTS	PA03656-Y109	BRAKE-FRAME
SPARE PARTS	PA03656-Y110	BR-IDLE-GEAR
SPARE PARTS	PA03656-Y112	EMPTY-ARM
SPARE PARTS	PA03656-Y113	PICK-ARM
SPARE PARTS	PA03656-Y114	ARM-ROLLER
SPARE PARTS	PA03656-Y121	EXIT-SPR-SPACE
SPARE PARTS	PA03656-Y123	LOCK-SPRING2
SPARE PARTS	PA03656-Y126	BR-IDLE-PIN
SPARE PARTS	PA03656-Y134	CIS-SPRING
SPARE PARTS	PA03656-Y135	FEED-SPRING
SPARE PARTS	PA03656-Y136	EXIT-SPRING
SPARE PARTS	PA03656-Y137	TOP-SPRING
SPARE PARTS	PA03656-Y141	LEVER
SPARE PARTS	PA03656-Y178	J-SHEET
SPARE PARTS	PA03656-Y179	CHUTER-SW-SPR
SPARE PARTS	PA03656-Y214	BR-PRESS-SPR2
SPARE PARTS	PA03656-Y217	RV-CABLE-SHEET
SPARE PARTS	PA03656-Y231	CHUTER-SW
SPARE PARTS	PA03656-Y511	SIDE-COVER-R
SPARE PARTS	PA03656-Y521	SIDE-COVER-L
SPARE PARTS	PA03656-Y821	CALIBRATION-SHEET
SPARE PARTS	PA03670-0013	PICK ROLLER S
SPARE PARTS	PA03670-D921	UPPER-UNIT
SPARE PARTS	PA03670-D925	UPPER-UNIT
SPARE PARTS	PA03670-D926	UPPER-UNIT
SPARE PARTS	PA03670-D929	UPPER UNIT
SPARE PARTS	PA03670-D931	BASE-UNIT
SPARE PARTS	PA03670-D935	BASE-UNIT
SPARE PARTS	PA03670-D936	BASE-UNIT
SPARE PARTS	PA03670-D937	BASE-UNIT
SPARE PARTS	PA03670-E901	BASE-ASSY
SPARE PARTS	PA03670-E905	BASE-ASSY
SPARE PARTS	PA03670-E906	BASE-ASSY
SPARE PARTS	PA03670-E912	GUIDE-P-ASSY
SPARE PARTS	PA03670-E919	FB MOTOR UNIT
SPARE PARTS	PA03670-E921	UPPER-ASSY
SPARE PARTS	PA03670-E925	UPPER-ASSY
SPARE PARTS	PA03670-E926	UPPER-ASSY
SPARE PARTS	PA03670-E929	UPPER ASSY
SPARE PARTS	PA03670-E931	OP-ASSY
SPARE PARTS	PA03670-E941	FB-TOP-COV-ASSY
SPARE PARTS	PA03670-E946	DOC-COV-ASSY
SPARE PARTS	PA03670-E950	OPT-BOX-UNIT
SPARE PARTS	PA03670-E951	OP-ASSY
SPARE PARTS	PA03670-E960	OPT-BOX-UNIT
SPARE PARTS	PA03670-E961	OPT-BOX-UNITS
SPARE PARTS	PA03670-E970	OPT-UNIT
SPARE PARTS	PA03670-E971	OPT-UNIT
SPARE PARTS	PA03670-E972	OPT-UNIT
SPARE PARTS	PA03670-E980	STACKER-UNIT
SPARE PARTS	PA03670-E985	CHUTER-UNIT
SPARE PARTS	PA03670-F161	SWITCH-ASSY-L5
SPARE PARTS	PA03670-F171	FRONT-COV-R-ASY

SPARE PARTS	PA03670-F181	F-COV-R-ASY-L5E
SPARE PARTS	PA03670-F377	P-ROLL-ASY-L5E
SPARE PARTS	PA03670-F378	P-ROLLER-EXIT-2
SPARE PARTS	PA03670-F720	BW ASSY
SPARE PARTS	PA03670-F901	PICK-MOTOR-ASSY
SPARE PARTS	PA03670-F902	PICK-SHAFT-ASSY
SPARE PARTS	PA03670-F903	EXIT-PINCH-ASSY
SPARE PARTS	PA03670-F905	FX-FRAME-ASSY
SPARE PARTS	PA03670-F909	FB MOTOR ASSY
SPARE PARTS	PA03670-F913	EXIT-PINCH-ASSY
SPARE PARTS	PA03670-F921	BR-SHAFT-ASSY
SPARE PARTS	PA03670-F925	RV-FRAME-ASSY
SPARE PARTS	PA03670-F926	GUIDE-R-ASSY
SPARE PARTS	PA03670-F928	RV-FRAME-ASSY
SPARE PARTS	PA03670-F946	DOC-EXT-FB
SPARE PARTS	PA03670-F955	FB-BASE-COVER
SPARE PARTS	PA03670-F956	CR-CABLE-ASSY
SPARE PARTS	PA03670-F960	SENSOR-ASSY
SPARE PARTS	PA03670-F965	LF-MOTOR
SPARE PARTS	PA03670-F971	EXTEND-ASSY
SPARE PARTS	PA03670-F972	STACKER-STOPPER
SPARE PARTS	PA03670-F975	STACKER-ADJ
SPARE PARTS	PA03670-K901	US-SENSOR-FX
SPARE PARTS	PA03670-K905	AC ADAPTER
SPARE PARTS	PA03670-K921	ADF-MOTOR
SPARE PARTS	PA03670-K922	LCD
SPARE PARTS	PA03670-K941	CONTROL-PCA-AL2
SPARE PARTS	PA03670-K943	CONTROL-PCA-AL3
SPARE PARTS	PA03670-K970	LED-PCA
SPARE PARTS	PA03670-K971	LED-PCA
SPARE PARTS	PA03670-K972	MIC-PCA
SPARE PARTS	PA03670-K973	LED-PCA
SPARE PARTS	PA03670-K975	JOINT-PCA
SPARE PARTS	PA03670-K976	IMP-CT
SPARE PARTS	PA03670-K981	PANEL-PCA-H
SPARE PARTS	PA03670-K982	PANEL-PCA-L
SPARE PARTS	PA03670-K983	PANEL-PCA-E
SPARE PARTS	PA03670-K984	PANEL-PCA-E35
SPARE PARTS	PA03670-K985	PANEL-PCA-E30
SPARE PARTS	PA03670-K986	PANEL-PCA-E25
SPARE PARTS	PA03670-K987	PANEL-PCA-E20
SPARE PARTS	PA03670-K991	CONTROL-PCA-AH
SPARE PARTS	PA03670-K992	CONTROL-PCA-FH
SPARE PARTS	PA03670-K993	CONTROL-PCA-AL
SPARE PARTS	PA03670-K994	CONTROL-PCA-FL
SPARE PARTS	PA03670-K997	CTRL-PCA2-AE
SPARE PARTS	PA03670-K998	CTRL-PCA2-FE
SPARE PARTS	PA03670-Y151	FRONT-COV-C
SPARE PARTS	PA03670-Y181	LED PIPE
SPARE PARTS	PA03670-Y182	LCD-PANEL
SPARE PARTS	PA03670-Y191	LCD-HOLDER
SPARE PARTS	PA03670-Y310	PICK-SHAFT-L5
SPARE PARTS	PA03670-Y320	PULLEY-GEAR-L5
SPARE PARTS	PA03670-Y321	PIC-W-GEAR-L5
SPARE PARTS	PA03670-Y340	SG-BLOCK
SPARE PARTS	PA03670-Y345	SG-CAM
SPARE PARTS	PA03670-Y373	SPACER-L5
SPARE PARTS	PA03670-Y376	FEED-SPRING-L5L
SPARE PARTS	PA03670-Y411	LOCK-LEVER
SPARE PARTS	PA03670-Y412	BEARING-POM
SPARE PARTS	PA03670-Y414	EMPTY-ARM
SPARE PARTS	PA03670-Y422	EMPTY-ARM

SPARE PARTS	PA03670-Y430	BR-FEED-GEAR
SPARE PARTS	PA03670-Y431	BR-REV-GEAR2
SPARE PARTS	PA03670-Y432	BR-REDUCE-GEAR
SPARE PARTS	PA03670-Y435	FEED-PULLEY-L5
SPARE PARTS	PA03670-Y440	COLLAR-L5
SPARE PARTS	PA03670-Y446	IM-J-SHEET
SPARE PARTS	PA03670-Y461	FEED-ROLLER-L5E
SPARE PARTS	PA03670-Y466	EXIT-ROLLER-L5E
SPARE PARTS	PA03670-Y611	DOC-SLIDER-L5
SPARE PARTS	PA03670-Y621	DOC-STOPPER-L5
SPARE PARTS	PA03670-Y690	US ADJ CHART(M10)
SPARE PARTS	PA03670-Y707	CAM SPRING RV
SPARE PARTS	PA03670-Y745	LED-Case
SPARE PARTS	PA03670-Y755	BEARING
SPARE PARTS	PA03670-Y761	FX-COVER-LID-R
SPARE PARTS	PA03670-Y771	FX-COVER-LID-L
SPARE PARTS	PA03670-Y798	PICK BEARING2(M10)
SPARE PARTS	PA03670-Y922	FRONT-COV-L
SPARE PARTS	PA03670-Y923	FRONT-COV-L
SPARE PARTS	PA03670-Y924	FRONT-COV-L
SPARE PARTS	PA03670-Y925	FRONT-COV-L
SPARE PARTS	PA03670-Y932	FRONT-COV-L
SPARE PARTS	PA03670-Y933	FRONT-COV-L
SPARE PARTS	PA03670-Y934	FRONT-COV-L
SPARE PARTS	PA03670-Y935	FRONT-COV-L
SPARE PARTS	PA03670-Y961	TOP COVER
SPARE PARTS	PA03684-D941	BASE UNIT
SPARE PARTS	PA03684-D971	UPPER UNIT
SPARE PARTS	PA03684-E041	OP ASSY
SPARE PARTS	PA03684-E910	CHUTER UNIT
SPARE PARTS	PA03684-E921	DOC COVER ASSY
SPARE PARTS	PA03684-E931	UPPER ASSY
SPARE PARTS	PA03684-E941	BASE ASSY
SPARE PARTS	PA03684-F621	TOP LID S ASSY
SPARE PARTS	PA03684-F908	FB BASE COVER
SPARE PARTS	PA03684-K903	CONTROL PCA FB
SPARE PARTS	PA03684-K907	PANEL PCA
SPARE PARTS	PA03684-Y703	LOGO SP30F
SPARE PARTS	PA03688-0081	ANTENNA
SPARE PARTS	PA03688-E107	PINCH-UNIT
SPARE PARTS	PA03688-F021	MOTOR-P-UNIT
SPARE PARTS	PA03688-F095	SWITCH
SPARE PARTS	PA03688-K951	CONTROL-PCA
SPARE PARTS	PA03688-K952	PANEL-PCA
SPARE PARTS	PA03688-K956	CONTROL-PCA2
SPARE PARTS	PA03688-K961	FIX-SUB-ASSY
SPARE PARTS	PA03688-Y025	LED-PIPE
SPARE PARTS	PA03688-Y027	BUTTON-STOPPER
SPARE PARTS	PA03688-Y070	CHUTER-SW
SPARE PARTS	PA03688-Y072	CHUTER-LOCK-R
SPARE PARTS	PA03688-Y073	CHUTER-LOCK-L
SPARE PARTS	PA03688-Y074	SW-SPRING
SPARE PARTS	PA03688-Y076	REDUCTION-GEAR1
SPARE PARTS	PA03688-Y077	REDUCTION-GEAR2
SPARE PARTS	PA03688-Y084	COVER-SEAL
SPARE PARTS	PA03688-Y091	BUTTON-PLATE
SPARE PARTS	PA03688-Y098	GEAR-SPACER
SPARE PARTS	PA03688-Y311	SIDE-COVER-L
SPARE PARTS	PA03688-Y326	SIDE-COVER-R(M10)(H
SPARE PARTS	PA03688-Y331	BUTTON
SPARE PARTS	PA03688-Y341	WPS-BUTTON
SPARE PARTS	PA03688-Y351	WI-FI-SW

SPARE PARTS	PA03688-Y402	TOP-COVER
SPARE PARTS	PA03688-Y406	TOP-COVER
SPARE PARTS	PA03706-D961	FIXED-UNIT
SPARE PARTS	PA03706-D983	LCD-UNIT(E)
SPARE PARTS	PA03706-D987	LCD-UNIT(EA)
SPARE PARTS	PA03706-D991	REVOLVE-UNIT
SPARE PARTS	PA03706-E902	FIX-SUB-UNIT
SPARE PARTS	PA03706-E941	SIDE-COV-L-ASY
SPARE PARTS	PA03706-E951	SIDE-COV-R-ASY
SPARE PARTS	PA03706-E952	CHUTE-ASSY
SPARE PARTS	PA03706-E956	BR-SHAFT-ASSY
SPARE PARTS	PA03706-E961	GUIDE-A
SPARE PARTS	PA03706-E981	STACKER-ASY
SPARE PARTS	PA03706-E987	N7100-CT
SPARE PARTS	PA03706-F060	SC-CT-PLATE-ASY
SPARE PARTS	PA03706-F361	CHUT-EXT-ASSY
SPARE PARTS	PA03706-K223	PACKAGE
SPARE PARTS	PA03706-K851	SSD-UNIT(E)
SPARE PARTS	PA03706-K855	SSD-UNIT(E)
SPARE PARTS	PA03706-K859	SSD-UNIT(EA)
SPARE PARTS	PA03706-K920	LAN-CABLE-UK
SPARE PARTS	PA03706-K924	4G_DDR3-SODIMM
SPARE PARTS	PA03706-K930	2G_DDR3-SODIMM
SPARE PARTS	PA03706-K931	AC ADAPTER
SPARE PARTS	PA03706-K941	LCD-CABLE
SPARE PARTS	PA03706-K942	USB-T-CABLE
SPARE PARTS	PA03706-K943	DC-CABLE
SPARE PARTS	PA03706-K945	USB-S-CABLE
SPARE PARTS	PA03706-K946	HK-RING
SPARE PARTS	PA03706-K947	TSC-CABLE
SPARE PARTS	PA03706-K949	BKL-CABLE
SPARE PARTS	PA03706-K951	SSD-UNIT
SPARE PARTS	PA03706-K955	SSD-UNIT
SPARE PARTS	PA03706-K959	SSD-UNIT
SPARE PARTS	PA03706-K964	RUBBER-FOOT
SPARE PARTS	PA03706-K971	N7100-TSC
SPARE PARTS	PA03706-K973	N7100-JNT
SPARE PARTS	PA03706-K978	US-SENSOR-FX
SPARE PARTS	PA03706-K979	SENSOR2
SPARE PARTS	PA03706-K984	MB-UNIT2
SPARE PARTS	PA03706-K985	STACKER-EXT1
SPARE PARTS	PA03706-K986	STACKER-EXT2
SPARE PARTS	PA03706-K990	TENSION-SPRING
SPARE PARTS	PA03706-Y021	LEVER
SPARE PARTS	PA03706-Y030	J-SHEET
SPARE PARTS	PA03706-Y041	STACKER-EXT
SPARE PARTS	PA03706-Y051	STACKER-EXT-2
SPARE PARTS	PA03706-Y395	ARM-ROLLER
SPARE PARTS	PA03708-0915	OUTER BOX
SPARE PARTS	PA03708-K900	AC ADAPTER
SPARE PARTS	PA03708-K920	FEED ROLLER
SPARE PARTS	PA03708-K921	EXIT ROLLER
SPARE PARTS	PA03708-K922	BRAKE COVER
SPARE PARTS	PA03708-K923	BRAKE SHAFT
SPARE PARTS	PA03708-K924	FRONT CIS UNIT
SPARE PARTS	PA03708-K925	PHOTO SENSOR
SPARE PARTS	PA03708-K926	US SENSOR
SPARE PARTS	PA03708-K927	US SENSOR PCA
SPARE PARTS	PA03708-K928	FOOT RUBBER
SPARE PARTS	PA03708-K930	CONTROL PCA 20
SPARE PARTS	PA03708-K931	CONTROL PCA 25
SPARE PARTS	PA03708-K932	CONTROL PCA 30

SPARE PARTS	PA03708-K940	TOP COVER UNIT
SPARE PARTS	PA03708-K941	PICK COVER
SPARE PARTS	PA03708-K942	PICK IDLE UNIT
SPARE PARTS	PA03708-K943	BACK CIS UNIT
SPARE PARTS	PA03708-K944	FFC CABLE OP
SPARE PARTS	PA03708-K945	FFC CABLE CIS
SPARE PARTS	PA03708-K946	PANEL PCA
SPARE PARTS	PA03708-K960	STACKER UNIT
SPARE PARTS	PA03708-K961	CHUTE UNIT
SPARE PARTS	PA03708-K970	SCREW B
SPARE PARTS	PA03708-K971	SCREW
SPARE PARTS	PA03708-K980	SHADE CHART 220
SPARE PARTS	PA03708-K981	CHART 40
SPARE PARTS	PA03708-K982	WAVING CHART 12
SPARE PARTS	PA03708-K983	35GX2 PAPER
SPARE PARTS	PA03708-K984	200G PAPER
SPARE PARTS	PA03708-K990	PLUG KIT EU
SPARE PARTS	PA03708-K996	PLUG KIT BR
SPARE PARTS	PA03708-K997	PLUG KIT CN
SPARE PARTS	PA03708-K998	PLUG KIT IN
SPARE PARTS	PA03710-1886	LED-ASSY-R-ATL
SPARE PARTS	PA03710-D821	UPPER-UNIT
SPARE PARTS	PA03710-D831	BASE-UNIT
SPARE PARTS	PA03710-E902	BASE-ASSY
SPARE PARTS	PA03710-E922	UPPER-ASSY
SPARE PARTS	PA03710-E932	OP-ASSY
SPARE PARTS	PA03710-E971	OPT-UNIT
SPARE PARTS	PA03710-E981	STACKER-UNIT
SPARE PARTS	PA03710-E986	CHUTER-UNIT
SPARE PARTS	PA03710-E991	IM-PINCH-ASSY
SPARE PARTS	PA03710-F280	BW-ASSY-ATL
SPARE PARTS	PA03710-F621	OUTER-BOX-IMBG
SPARE PARTS	PA03710-F906	PICK-MOTOR-ASSY
SPARE PARTS	PA03710-F907	FE-PINCH-ROLLER
SPARE PARTS	PA03710-F908	EX-PINCH-ROLLER
SPARE PARTS	PA03710-F911	GLASS-UNIT-F
SPARE PARTS	PA03710-F912	GLASS-UNIT-B
SPARE PARTS	PA03710-F913	LED-ASSY-F
SPARE PARTS	PA03710-F914	LED-ASSY-B
SPARE PARTS	PA03710-F915	G-UNIT-F-SHEET
SPARE PARTS	PA03710-F916	G-UNIT-B-SHEET
SPARE PARTS	PA03710-F920	BR-SHAFT-ASSY
SPARE PARTS	PA03710-F922	FE-ROLLER-ASSY
SPARE PARTS	PA03710-F923	EX-ROLLER-ASSY
SPARE PARTS	PA03710-F927	GUIDE-R-ASSY
SPARE PARTS	PA03710-F929	FX-FRAME-ASSY
SPARE PARTS	PA03710-F930	RV-FRAME-ASSY
SPARE PARTS	PA03710-F931	M-FE-LEVER-ASSY
SPARE PARTS	PA03710-F932	GLASS-F-ASSY
SPARE PARTS	PA03710-F933	GLASS-B-ASSY
SPARE PARTS	PA03710-F935	TOP-COVER-ASSY
SPARE PARTS	PA03710-F976	STACKER-ADJ
SPARE PARTS	PA03710-F990	IM-GUIDE-UNIT
SPARE PARTS	PA03710-F991	B-IM-TOP-COV
SPARE PARTS	PA03710-F993	IM-SUB-GUIDE
SPARE PARTS	PA03710-G035	P-ROLLER-ATL
SPARE PARTS	PA03710-G036	P-ROLL-EXIT-ATL
SPARE PARTS	PA03710-G441	SWITCH-ASY-ATL
SPARE PARTS	PA03710-K902	PICK MT CABLE
SPARE PARTS	PA03710-K907	AC ADAPTER
SPARE PARTS	PA03710-K908	SWITCH
SPARE PARTS	PA03710-K909	M-FEED-SW

SPARE PARTS	PA03710-K931	ADF-MOTOR
SPARE PARTS	PA03710-K932	LCD
SPARE PARTS	PA03710-K961	PANEL-PCA-H
SPARE PARTS	PA03710-K962	PANEL-PCA-L
SPARE PARTS	PA03710-K971	CONTROL-PCA-H
SPARE PARTS	PA03710-K973	CONTROL-PCA-L
SPARE PARTS	PA03710-K983	MIC-PCA
SPARE PARTS	PA03710-K990	USB-CABLE
SPARE PARTS	PA03710-K991	IMG-PRT3
SPARE PARTS	PA03710-K992	PR HARNESS
SPARE PARTS	PA03710-K996	IM-MT-B-CABLE
SPARE PARTS	PA03710-Y011	PIC-D-SHAFT
SPARE PARTS	PA03710-Y020	FEED-SPRING-ATL
SPARE PARTS	PA03710-Y065	CABLE-SHEET(M10)(S
SPARE PARTS	PA03710-Y103	J-SHEET-ATL
SPARE PARTS	PA03710-Y123	BR-FEED-GEAR
SPARE PARTS	PA03710-Y127	BRAKE-GEAR-ATL(M10)(S
SPARE PARTS	PA03710-Y130	BR-IDLE-GEAR
SPARE PARTS	PA03710-Y131	BR-REV-GEAR1
SPARE PARTS	PA03710-Y142	BEARING-HOLD
SPARE PARTS	PA03710-Y170	J-ASSIST-SHEET
SPARE PARTS	PA03710-Y282	CHANGE-LINK-ATL
SPARE PARTS	PA03710-Y294	LED-PLATE
SPARE PARTS	PA03710-Y295	CASE-SHEET-FX
SPARE PARTS	PA03710-Y296	CASE-SHEET-RV
SPARE PARTS	PA03710-Y411	FRONT-COV-C-ATL
SPARE PARTS	PA03710-Y425	FRONT-COV-L-ATL
SPARE PARTS	PA03710-Y426	FRONT-COV-L-ATL
SPARE PARTS	PA03710-Y431	FRONT-COV-R-ATL
SPARE PARTS	PA03710-Y521	CHUT-EXT1-ATL
SPARE PARTS	PA03710-Y524	CHUT-EXT2-ATL
SPARE PARTS	PA03710-Y631	IM-STK-ANG-ADJ
SPARE PARTS	PA03710-Y645	IM-GUIDE-SHEET
SPARE PARTS	PA03710-Y670	IM-FEED-ROLLER
SPARE PARTS	PA03710-Y671	IM-EXIT-ROLLER
SPARE PARTS	PA03710-Y760	TENSION-SPRING
SPARE PARTS	PA03740-D505	FB-COVER-ASSY
SPARE PARTS	PA03740-D506	FB-COVER-ASSY
SPARE PARTS	PA03740-D957	DOCUMENT-COVER
SPARE PARTS	PA03740-D958	FB-UNIT
SPARE PARTS	PA03740-D970	FIX-UNIT
SPARE PARTS	PA03740-D971	REV-UNIT
SPARE PARTS	PA03740-D972	REV-UNIT
SPARE PARTS	PA03740-D974	FIX-UNIT
SPARE PARTS	PA03740-D980	CHUTER-UNIT
SPARE PARTS	PA03740-D982	FB-UNIT
SPARE PARTS	PA03740-D985	STACKER-UNIT
SPARE PARTS	PA03740-D989	HINGE-UNIT
SPARE PARTS	PA03740-E301	TOP-COV-ASSY
SPARE PARTS	PA03740-E901	DOC-COVER-ASSY
SPARE PARTS	PA03740-E931	PANEL-UNIT-A
SPARE PARTS	PA03740-E932	PANEL-UNIT-A
SPARE PARTS	PA03740-E934	PANEL-UNIT-B
SPARE PARTS	PA03740-E935	PANEL-UNIT-B
SPARE PARTS	PA03740-E951	IM-PINCH-ASSY
SPARE PARTS	PA03740-E955	IMG-PRT4
SPARE PARTS	PA03740-E971	REV-ASSY
SPARE PARTS	PA03740-E974	FIX-ASSY
SPARE PARTS	PA03740-E977	OPTICAL-UNIT-FB
SPARE PARTS	PA03740-E982	PANEL-UNIT-FB
SPARE PARTS	PA03740-E983	PANEL-UNIT-FB
SPARE PARTS	PA03740-E984	PANEL-UNIT-FBS

SPARE PARTS	PA03740-E985	PANEL-UNIT-FBS
SPARE PARTS	PA03740-E992	FB-MOTOR
SPARE PARTS	PA03740-E996	PANEL-UNIT-A
SPARE PARTS	PA03740-E997	PANEL-UNIT-A
SPARE PARTS	PA03740-F002	LOCK-PLATE-ASSY
SPARE PARTS	PA03740-F106	M-FEED-ASSY
SPARE PARTS	PA03740-F370	BOTTOM-COV-ASSY
SPARE PARTS	PA03740-F372	SIDE-COV-L-ASSY
SPARE PARTS	PA03740-F374	SIDE-COV-L-ASSY
SPARE PARTS	PA03740-F376	SIDE-COV-L-ASSY
SPARE PARTS	PA03740-F380	SIDE-COV-R-ASSY
SPARE PARTS	PA03740-F382	SIDE-COV-R-ASSY
SPARE PARTS	PA03740-F384	SIDE-COV-R-ASSY
SPARE PARTS	PA03740-F536	BOTTOM-UNIT-ME3
SPARE PARTS	PA03740-F651	OUTER-BOX-LA
SPARE PARTS	PA03740-F871	IM-ATTACH-UNIT
SPARE PARTS	PA03740-F941	CHUT-BASE-ASSY
SPARE PARTS	PA03740-F942	CHUT-B-PLT-ASSY
SPARE PARTS	PA03740-F943	SLIP-BASE-ASSY
SPARE PARTS	PA03740-F944	CHUT-GU-R-ASSY
SPARE PARTS	PA03740-F945	CHUT-GU-L-ASSY
SPARE PARTS	PA03740-F946	FB-SIDE-COVER-R
SPARE PARTS	PA03740-F947	RV-FRAME-ASSY
SPARE PARTS	PA03740-F948	FX-FRAME-ASSY
SPARE PARTS	PA03740-F966	LED-CHUNIT
SPARE PARTS	PA03740-F970	IM-TOP-COV
SPARE PARTS	PA03740-F975	FEED-ROLL-ASSY
SPARE PARTS	PA03740-F976	EXIT-ROLL-ASSY
SPARE PARTS	PA03740-F978	BR-SHAFT-ASSY
SPARE PARTS	PA03740-F980	PLANET-ASSY
SPARE PARTS	PA03740-F981	SEP-SHAFT-ASSY
SPARE PARTS	PA03740-F982	SEPA-SE-UNIT
SPARE PARTS	PA03740-F983	PIC-ARM-ASSY
SPARE PARTS	PA03740-F985	GUIDE-P
SPARE PARTS	PA03740-F986	GUIDE-R-ASSY
SPARE PARTS	PA03740-F987	OP-ASSY
SPARE PARTS	PA03740-F988	OP-ASSY-FB
SPARE PARTS	PA03740-F990	PICK-MOTOR-ASSY
SPARE PARTS	PA03740-F991	FEED-MOTOR
SPARE PARTS	PA03740-F992	ARM-MOTOR-UNIT
SPARE PARTS	PA03740-F995	FEED-PINCH-ROLL
SPARE PARTS	PA03740-F996	EXIT-PINCH-ROLL
SPARE PARTS	PA03740-F997	OP-ASSY
SPARE PARTS	PA03740-F998	OP-ASSY-FB
SPARE PARTS	PA03740-G005	PINCH-ROLLER
SPARE PARTS	PA03740-G364	SWITCH-ASY-ADF(M10)
SPARE PARTS	PA03740-G365	SWITCH-ASY-FB(M10)
SPARE PARTS	PA03740-G531	BTM-JOINT
SPARE PARTS	PA03740-K903	CCD-CLK-CABLE-F
SPARE PARTS	PA03740-K904	CCD-CLK-CABLE-B
SPARE PARTS	PA03740-K920	SENSOR
SPARE PARTS	PA03740-K922	FEED-MT-CABLE
SPARE PARTS	PA03740-K925	RUBBER-FOOT-S
SPARE PARTS	PA03740-K927	RUBBER-FOOT
SPARE PARTS	PA03740-K930	EMP-ARM
SPARE PARTS	PA03740-K932	PANEL-PCA-A
SPARE PARTS	PA03740-K933	LCD
SPARE PARTS	PA03740-K935	PANEL-PCA-B
SPARE PARTS	PA03740-K938	ADF-CABLE
SPARE PARTS	PA03740-K940	LCD-FB
SPARE PARTS	PA03740-K945	PANEL-PCA-FB
SPARE PARTS	PA03740-K947	PANEL-PCA-FBS

SPARE PARTS	PA03740-K948	CHUTER-ROLLER
SPARE PARTS	PA03740-K950	CONTROL-PCA
SPARE PARTS	PA03740-K952	CONTROL-PCA
SPARE PARTS	PA03740-K953	CONTROL-PCA
SPARE PARTS	PA03740-K956	CONTROL-PCA-FB
SPARE PARTS	PA03740-K957	CONTROL-PCA-FBS
SPARE PARTS	PA03740-K958	CONTROL-PCA-FBS
SPARE PARTS	PA03740-K959	CSL-R-L-HNS
SPARE PARTS	PA03740-K960	FG-HARNESS
SPARE PARTS	PA03740-K962	SPACER-KIT
SPARE PARTS	PA03740-K964	FB-JUNCTION-PCA
SPARE PARTS	PA03740-K966	CONTROL-PCA-FB
SPARE PARTS	PA03740-K967	CONTROL-PCA-FBS
SPARE PARTS	PA03740-K973	FB-IFA-PCA
SPARE PARTS	PA03740-K978	PR-HARNESS
SPARE PARTS	PA03740-K980	IM-GUIDE-SHEET2
SPARE PARTS	PA03740-K982	IM-MT-CABLE
SPARE PARTS	PA03740-K990	AC-ADAPTER
SPARE PARTS	PA03740-K995	CONTROL-PCA
SPARE PARTS	PA03740-K996	CONTROL-PCA
SPARE PARTS	PA03740-Y012	SCREW-PLATE
SPARE PARTS	PA03740-Y016	SCREW-PIN
SPARE PARTS	PA03740-Y025	PICK-REDU-GEAR
SPARE PARTS	PA03740-Y028	PICK-D-GEAR
SPARE PARTS	PA03740-Y029	PICK-REDU-GEAR2
SPARE PARTS	PA03740-Y038	SENSOR-PIPE
SPARE PARTS	PA03740-Y073	ENC-SPRING-ME3
SPARE PARTS	PA03740-Y075	SLIDE-ARM-ME3
SPARE PARTS	PA03740-Y102	FLCM-SPRING-R
SPARE PARTS	PA03740-Y103	FLCM-SPRING-L
SPARE PARTS	PA03740-Y110	LOCK-LEVER (M10)(S
SPARE PARTS	PA03740-Y111	LOCK-LEVER-COV
SPARE PARTS	PA03740-Y112	GUIDE-C
SPARE PARTS	PA03740-Y113	FG-SPRING-RV
SPARE PARTS	PA03740-Y114	CABLE-GUIDE
SPARE PARTS	PA03740-Y116	DUST-FOAM-R1
SPARE PARTS	PA03740-Y125	J-SHEET-ME3
SPARE PARTS	PA03740-Y130	RV-COVER
SPARE PARTS	PA03740-Y143	ARM-SPRING-L
SPARE PARTS	PA03740-Y152	ARM-TOP
SPARE PARTS	PA03740-Y153	BRAKE-ONEWAY
SPARE PARTS	PA03740-Y172	ARM-CAM
SPARE PARTS	PA03740-Y176	ARM-GEAR
SPARE PARTS	PA03740-Y177	ARM-SE-GEAR
SPARE PARTS	PA03740-Y192	BRAKE-FRAME
SPARE PARTS	PA03740-Y194	BR-PRESS-SPRING
SPARE PARTS	PA03740-Y195	BR-PRESS-SW
SPARE PARTS	PA03740-Y196	BRAKE-SHAFT-ME3
SPARE PARTS	PA03740-Y197	BRAKE-GEAR (M10)(S
SPARE PARTS	PA03740-Y198	BR-RV-SHAFT-ME3
SPARE PARTS	PA03740-Y199	BR-ADJUSTER
SPARE PARTS	PA03740-Y205	ADF-JOINT-COV
SPARE PARTS	PA03740-Y341	OP-FG-PLATE
SPARE PARTS	PA03740-Y351	OP-CASE-ADF
SPARE PARTS	PA03740-Y352	OP-CASE-ADF
SPARE PARTS	PA03740-Y360	BACK-COVER
SPARE PARTS	PA03740-Y381	OP-CASE-FB
SPARE PARTS	PA03740-Y382	OP-CASE-FB
SPARE PARTS	PA03740-Y391	OP-FG-PLT-FB
SPARE PARTS	PA03740-Y402	CHUT-COVER
SPARE PARTS	PA03740-Y403	CHUT-EXT
SPARE PARTS	PA03740-Y407	CHUT-ROLL-COV

SPARE PARTS	PA03740-Y409	CLOSE-SPRING
SPARE PARTS	PA03740-Y410	CHUT-PULLEY2
SPARE PARTS	PA03740-Y412	CHUT-LOCK
SPARE PARTS	PA03740-Y413	CHUT-GRIP-L
SPARE PARTS	PA03740-Y414	CHUT-GRIP-R
SPARE PARTS	PA03740-Y416	SLIP-COVER
SPARE PARTS	PA03740-Y417	SLIP-SPRING
SPARE PARTS	PA03740-Y422	CHUT-PULLEY1
SPARE PARTS	PA03740-Y423	CHUT-TENSIONER
SPARE PARTS	PA03740-Y426	CHUT-SIGN-R
SPARE PARTS	PA03740-Y427	CHUT-SIGN-L
SPARE PARTS	PA03740-Y430	CHUT-GEAR
SPARE PARTS	PA03740-Y433	CHUT-SHAFT-S
SPARE PARTS	PA03740-Y434	LMT ADAPTER
SPARE PARTS	PA03740-Y451	STK-BASE
SPARE PARTS	PA03740-Y452	STK-COVER
SPARE PARTS	PA03740-Y453	STK-EXT
SPARE PARTS	PA03740-Y454	STK-STOPPER
SPARE PARTS	PA03740-Y455	STK-GUIDE-L
SPARE PARTS	PA03740-Y456	STK-GUIDE-R
SPARE PARTS	PA03740-Y460	STK-GUIDE-BASE
SPARE PARTS	PA03740-Y462	STK-GUIDE-PLT
SPARE PARTS	PA03740-Y503	IF-CABLE-COVER
SPARE PARTS	PA03740-Y531	FB-SIDE-COVER-L
SPARE PARTS	PA03740-Y540	FB-BACK-COVER
SPARE PARTS	PA03740-Y541	FB-TENSION-SPR
SPARE PARTS	PA03740-Y554	CR COVER
SPARE PARTS	PA03740-Y570	DOC-LID
SPARE PARTS	PA03740-Y579	D-LOCK-SHAFT2
SPARE PARTS	PA03740-Y661	IM-F-ROLLER
SPARE PARTS	PA03740-Y662	IM-E-ROLLER
SPARE PARTS	PA03750-D901	REVOLVE-UNIT
SPARE PARTS	PA03750-D931	FIXED-UNIT
SPARE PARTS	PA03750-E901	FIX-SUB-UNIT
SPARE PARTS	PA03750-E911	SIDE-COVER-L
SPARE PARTS	PA03750-E921	SIDE-COVER-R
SPARE PARTS	PA03750-E931	OP-ASSY
SPARE PARTS	PA03750-E942	CONTROL-PCA2
SPARE PARTS	PA03750-E951	GUIDE-A
SPARE PARTS	PA03750-E961	CHUTE-ASSY
SPARE PARTS	PA03750-E971	STACKER-ASSY
SPARE PARTS	PA03750-E983	GUIDE-P-ASSY
SPARE PARTS	PA03750-E984	GUIDE-P-ASSY
SPARE PARTS	PA03750-E992	GUIDE-R-ASSY
SPARE PARTS	PA03750-E993	GUIDE-R-ASSY
SPARE PARTS	PA03750-K930	USB-CABLE-UK
SPARE PARTS	PA03750-K951	PANEL-PCA
SPARE PARTS	PA03750-K961	FEED-ROLLER
SPARE PARTS	PA03750-K971	EXIT-ROLLER
SPARE PARTS	PA03750-K981	STACKER-EXIT
SPARE PARTS	PA03750-Y135	J-SHEET-M
SPARE PARTS	PA03750-Y141	LEVER
SPARE PARTS	PA03750-Y151	CABLE-SHEET
SPARE PARTS	PA03750-Y152	OP-SHEET
SPARE PARTS	PA03750-Y241	STACKER
SPARE PARTS	PA03750-Y251	STACKER-EXT
SPARE PARTS	PA03750-Y341	CHUT-EXT1
SPARE PARTS	PA03750-Y351	CHUT-EXT2
SPARE PARTS	PA03751-D800	DOC-COV-UNIT-FB
SPARE PARTS	PA03751-K901	CONTROL-PCA
SPARE PARTS	PA03751-K903	OP-ASSY
SPARE PARTS	PA03751-K904	PANEL-PCA

SPARE PARTS	PA03751-K912	COVER-A4FB-UNIT
SPARE PARTS	PA03753-K917	BTM COV UNIT
SPARE PARTS	PA03753-K919	MAIN PCA HOLD
SPARE PARTS	PA03753-K920	BRUSH(M100)
SPARE PARTS	PA03753-K921	FRONT COVER
SPARE PARTS	PA03753-K924	JOINT PCA
SPARE PARTS	PA03753-K932	CHUTER UNIT
SPARE PARTS	PA03753-K933	DOC COVER B
SPARE PARTS	PA03753-K934	DOC COVER W
SPARE PARTS	PA03753-K937	BASE UNIT
SPARE PARTS	PA03753-K939	PANEL PCBA
SPARE PARTS	PA03753-K940	PANEL UNDER COV
SPARE PARTS	PA03753-K947	MAIN PCA
SPARE PARTS	PA03753-K948	PICK SHEET(M50)
SPARE PARTS	PA03753-K949	EXIT SHEET(M50)
SPARE PARTS	PA03753-K951	F IN COV UNIT
SPARE PARTS	PA03753-K952	ADF UP COV UNIT
SPARE PARTS	PA03753-K953	ADF UNIT
SPARE PARTS	PA03753-K955	EMPTY ARM
SPARE PARTS	PA03753-K956	BACK CIS SHEET(M20)
SPARE PARTS	PA03753-K958	US SENSOR RX
SPARE PARTS	PA03753-K962	SCREW TS3-6N(M1000)
SPARE PARTS	PA03753-K963	SCREW TS3-6 B(M1000)
SPARE PARTS	PA03753-K964	SCREW M3-6 W(M1000)
SPARE PARTS	PA03753-K965	SCREW M3-6 F(M1000)
SPARE PARTS	PA03753-K966	SCREW M3-6(M1000)
SPARE PARTS	PA03753-K967	SCREW TS26-7(M1000)
SPARE PARTS	PA03753-K968	SCREW TS3-8(M1000)
SPARE PARTS	PA03753-K969	SCREW TS3-10(M1000)
SPARE PARTS	PA03753-K970	SCREW M3-10 R(M1000)
SPARE PARTS	PA03753-K971	SCREW M3-11 R(M1000)
SPARE PARTS	PA03753-K972	SCREW TS3-8 B(M1000)
SPARE PARTS	PA03753-K973	SCREW TS3-8 P(M1000)
SPARE PARTS	PA03753-K978	PANEL COVER
SPARE PARTS	PA03753-K981	USB CABLE(M5)
SPARE PARTS	PA03753-K982	AC ADAPTER(M2)
SPARE PARTS	PA03753-K983	AC CODESET EUR(M5)
SPARE PARTS	PA03753-K984	AC CODESET UK(M5)
SPARE PARTS	PA03753-K985	AC CODESET FCPA(M5)
SPARE PARTS	PA03753-K986	AC CODESET IND(M5)
SPARE PARTS	PA03753-K987	AC CODESET JPN(M5)
SPARE PARTS	PA03753-K991	TEST CHART SET
SPARE PARTS	PA03753-K992	US CHART SET
SPARE PARTS	PA03753-K998	OUTER BOX
SPARE PARTS	PA03753-K999	PANEL COVER
SPARE PARTS	PA03768-E901	BASE-ASSY
SPARE PARTS	PA03768-E952	FRONT-COV-ASSY
SPARE PARTS	PA03768-E970	OPT-UNIT
SPARE PARTS	PA03768-E985	CHUTER-UNIT
SPARE PARTS	PA03768-G482	SWITCH-ASSY
SPARE PARTS	PA03768-K901	US-SENSOR-FX
SPARE PARTS	PA03768-K910	AC-CORDSET-UK
SPARE PARTS	PA03768-K911	USB-CABLE-UK
SPARE PARTS	PA03768-K981	CONTROL-PCA
SPARE PARTS	PA03768-K991	CONTROL-PCA
SPARE PARTS	PA03768-Y452	FRONT-COVER
SPARE PARTS	PA03770-D961	REVOLVE-UNIT
SPARE PARTS	PA03770-D966	REVOLVE-UNIT
SPARE PARTS	PA03770-D971	REVOLVE-UNIT
SPARE PARTS	PA03770-D972	TOP-COV-F-ASSY
SPARE PARTS	PA03770-D973	FIXED-UNIT
SPARE PARTS	PA03770-D975	FIXED-UNIT-EH

SPARE PARTS	PA03770-D977	TOP-COV-F-ASSY
SPARE PARTS	PA03770-D986	TOP-COV-EH-F-AY
SPARE PARTS	PA03770-D988	TOP-COV-EH-F-AY
SPARE PARTS	PA03770-E972	CIS-UNIT-B
SPARE PARTS	PA03770-E973	FIX-SUB-UNIT
SPARE PARTS	PA03770-E974	MOTOR-UNIT
SPARE PARTS	PA03770-E975	CIS-UNIT-F
SPARE PARTS	PA03770-E976	CONTROL-PCA
SPARE PARTS	PA03770-E977	LID-ASSY
SPARE PARTS	PA03770-E978	GUIDE-A
SPARE PARTS	PA03770-E979	CHUT-ASSY
SPARE PARTS	PA03770-E980	STACKER-ASSY
SPARE PARTS	PA03770-E981	CIS-UNIT-F
SPARE PARTS	PA03770-E982	CIS-UNIT-B
SPARE PARTS	PA03770-E983	LID-ASSY
SPARE PARTS	PA03770-E984	CHUT-ASSY
SPARE PARTS	PA03770-E985	STACKER-ASSY(H
SPARE PARTS	PA03770-E988	GUIDE-A
SPARE PARTS	PA03770-E990	CONT-EH-PCA
SPARE PARTS	PA03770-E992	CHUT-EH-ASSY
SPARE PARTS	PA03770-E993	CHUT-EH-ASSY
SPARE PARTS	PA03770-E994	MOTOR-UNIT-EH
SPARE PARTS	PA03770-E995	CIS-UNIT-F
SPARE PARTS	PA03770-E996	CIS-UNIT-B
SPARE PARTS	PA03770-E997	CONT-EH-PCA
SPARE PARTS	PA03770-F331	CHUT-EXT-COV-AY
SPARE PARTS	PA03770-F332	CHUT-EXT-COV-AY
SPARE PARTS	PA03770-F333	CHUT-EXT-COV-AY
SPARE PARTS	PA03770-F335	CHUT-EXT-COV-AY(M10)
SPARE PARTS	PA03770-F336	CHUT-EXT-COV-AY
SPARE PARTS	PA03770-F337	CHUT-EXT-COV-AY
SPARE PARTS	PA03770-F451	RECEIPT-ASSY
SPARE PARTS	PA03770-F455	RECEIPT-ASSY
SPARE PARTS	PA03770-F971	GEAR-BOX-ASSY
SPARE PARTS	PA03770-G145	PINCH-ROLLER2
SPARE PARTS	PA03770-K021	PACKAGE
SPARE PARTS	PA03770-K561	PACKAGE-M
SPARE PARTS	PA03770-K941	AC CORDSET KIT
SPARE PARTS	PA03770-K942	AC CORDSET KIT
SPARE PARTS	PA03770-K943	AC CORDSET KIT
SPARE PARTS	PA03770-K971	JNT-PCA
SPARE PARTS	PA03770-K973	LCD
SPARE PARTS	PA03770-K974	STACKER-EXTEND
SPARE PARTS	PA03770-K975	USB-CABLE
SPARE PARTS	PA03770-K976	AC-ADAPTER
SPARE PARTS	PA03770-K977	TORQUE-DUMPER
SPARE PARTS	PA03770-K984	SIDE-COVER-R
SPARE PARTS	PA03770-K985	SIDE-COVER-L
SPARE PARTS	PA03770-K986	FG-HARNESS
SPARE PARTS	PA03770-K987	STACKER-EXTEND
SPARE PARTS	PA03770-K988	SIDE-COVER-R
SPARE PARTS	PA03770-K989	SIDE-COVER-L
SPARE PARTS	PA03770-K991	AC CORDSET KIT
SPARE PARTS	PA03770-K992	AC-CORDSET-UK
SPARE PARTS	PA03770-K993	USB-CABLE-UK
SPARE PARTS	PA03770-Y001	FIX-FRAME
SPARE PARTS	PA03770-Y010	SG-CAM(M10)
SPARE PARTS	PA03770-Y023	BRAKE-LINK-ARM
SPARE PARTS	PA03770-Y027	BR-LINK-SPRING
SPARE PARTS	PA03770-Y030	DAMP-REDU-GEAR
SPARE PARTS	PA03770-Y031	DAMP-GEAR
SPARE PARTS	PA03770-Y032	CHUT-SW

SPARE PARTS	PA03770-Y033	CHUT-SW-SPRING
SPARE PARTS	PA03770-Y040	RUBBER-FOOT-S
SPARE PARTS	PA03770-Y053	FG-PLATE1
SPARE PARTS	PA03770-Y054	FG-PLATE2
SPARE PARTS	PA03770-Y062	US-FG-PLATE
SPARE PARTS	PA03770-Y065	FG-PLATE-USB
SPARE PARTS	PA03770-Y079	REDU-GEAR2
SPARE PARTS	PA03770-Y080	IDLE-PS-GEAR
SPARE PARTS	PA03770-Y081	PLANET-GEAR
SPARE PARTS	PA03770-Y082	RV-IDLE-GEAR
SPARE PARTS	PA03770-Y100	REV-FRAME
SPARE PARTS	PA03770-Y131	LEVER
SPARE PARTS	PA03770-Y135	LEVER
SPARE PARTS	PA03770-Y140	REV-FRAME
SPARE PARTS	PA03770-Y172	FG-SPRING-LCD
SPARE PARTS	PA03770-Y215	OP-COVER
SPARE PARTS	PA03770-Y950	TEST CHART No.88
SPARE PARTS	PA03795-D360	RECEIPT-UNIT
SPARE PARTS	PA03795-D901	FIXED-UNIT
SPARE PARTS	PA03795-D911	FIXED-UNIT
SPARE PARTS	PA03795-D921	REV-UNIT
SPARE PARTS	PA03795-D941	REV-UNIT
SPARE PARTS	PA03795-D951	STACKER-UNIT
SPARE PARTS	PA03795-E901	CHUTER-ASSY
SPARE PARTS	PA03795-E902	CHUTER-ASSY
SPARE PARTS	PA03795-E911	GUIDE-R-ASSY
SPARE PARTS	PA03795-F902	ADF-MOTOR
SPARE PARTS	PA03795-F911	GEAR-UNIT
SPARE PARTS	PA03795-F912	U-MOTOR
SPARE PARTS	PA03795-F921	U-GUIDE-ASSY
SPARE PARTS	PA03795-F922	U-GUIDE-ASSY
SPARE PARTS	PA03795-F942	BASE-COV-UNIT
SPARE PARTS	PA03795-F951	CIS-UNIT-F
SPARE PARTS	PA03795-F952	CIS-UNIT-R
SPARE PARTS	PA03795-F971	U-PINCH-ROLL
SPARE PARTS	PA03795-F981	F-COV-ASSY
SPARE PARTS	PA03795-F985	F-COV-ASSY
SPARE PARTS	PA03795-F991	USB-COV-ASSY
SPARE PARTS	PA03795-K901	UTOP-COVER
SPARE PARTS	PA03795-K905	F-PINCH-ROLL
SPARE PARTS	PA03795-K906	E-PINCH-ROLL
SPARE PARTS	PA03795-K910	ADJ-CHART-KIT
SPARE PARTS	PA03795-K911	GUIDE-A
SPARE PARTS	PA03795-K915	FEED-ROLLER
SPARE PARTS	PA03795-K916	EXIT-ROLLER
SPARE PARTS	PA03795-K917	U-FEED-ROLLER
SPARE PARTS	PA03795-K921	US-SE
SPARE PARTS	PA03795-K923	EMP-SE
SPARE PARTS	PA03795-K925	REV-SE
SPARE PARTS	PA03795-K931	CONTROL-PCA
SPARE PARTS	PA03795-K933	OP-PANEL
SPARE PARTS	PA03795-K935	FIX-SE
SPARE PARTS	PA03795-K938	EXIT-FG-PLATE
SPARE PARTS	PA03795-K941	RUBBER-FOOT
SPARE PARTS	PA03795-K945	PICK-BEARING
SPARE PARTS	PA03795-K951	AC-ADAPTER
SPARE PARTS	PA03795-K955	PINCH-BEARING
SPARE PARTS	PA03795-K958	TENSION-JIG
SPARE PARTS	PA03795-K962	AC-CORDSET-U
SPARE PARTS	PA03795-K963	AC-CORDSET-C
SPARE PARTS	PA03795-K964	AC-CORDSET-E
SPARE PARTS	PA03795-K965	AC-CORDSET-UK

SPARE PARTS	PA03795-K968	PACKAGE
SPARE PARTS	PA03795-Y041	STK-STOPPER
SPARE PARTS	PA03795-Y042	STK-ROLLER
SPARE PARTS	PA03795-Y043	STK-SPRING
SPARE PARTS	PA03795-Y066	STK-TQ-GEAR1
SPARE PARTS	PA03795-Y068	STK-TQ-GEAR2
SPARE PARTS	PA03795-Y069	STK-TQ-IDL-GEAR
SPARE PARTS	PA03795-Y071	STK-CNT-GEAR
SPARE PARTS	PA03795-Y100	FIXED-FRAME
SPARE PARTS	PA03795-Y101	LED-PIPE
SPARE PARTS	PA03795-Y107	MOT-RED-GEAR
SPARE PARTS	PA03795-Y108	FEED-BEA-GEAR
SPARE PARTS	PA03795-Y110	DUST-COV-S
SPARE PARTS	PA03795-Y114	TENSION-COLLAR
SPARE PARTS	PA03795-Y115	FEED-GEAR
SPARE PARTS	PA03795-Y116	FG-BEARING
SPARE PARTS	PA03795-Y118	EXIT-BEA-GEAR
SPARE PARTS	PA03795-Y119	U-RED-GEAR
SPARE PARTS	PA03795-Y120	U-IDLE-GEAR
SPARE PARTS	PA03795-Y121	U-ONEWAY-GEAR
SPARE PARTS	PA03795-Y123	U-FEED-BEARING
SPARE PARTS	PA03795-Y129	UG-IDLE-GEAR
SPARE PARTS	PA03795-Y140	MOT-RED-GEAR2
SPARE PARTS	PA03795-Y149	MOT-DUST-SHEET
SPARE PARTS	PA03795-Y179	DUST-SHEET-JC
SPARE PARTS	PA03795-Y191	J-SHEET
SPARE PARTS	PA03795-Y200	REV-FRAME
SPARE PARTS	PA03795-Y202	LOCK-ARM-L
SPARE PARTS	PA03795-Y203	LOCK-ARM-R
SPARE PARTS	PA03795-Y205	LOCK-SPRING
SPARE PARTS	PA03795-Y221	UNIV-JOINT-A
SPARE PARTS	PA03795-Y222	UNIV-JOINT-B
SPARE PARTS	PA03795-Y223	UNIV-JOINT-D
SPARE PARTS	PA03795-Y224	P-ROLLER-GEAR
SPARE PARTS	PA03795-Y225	FEED-SPRING
SPARE PARTS	PA03795-Y230	PIC-ONEWAY-GEAR
SPARE PARTS	PA03795-Y231	PIC-FLANGE
SPARE PARTS	PA03795-Y232	PICK-SHAFT-SPR
SPARE PARTS	PA03795-Y234	PICK-RED-GEAR
SPARE PARTS	PA03795-Y239	EXIT-SPRING
SPARE PARTS	PA03795-Y240	EMPTY-ARM-2
SPARE PARTS	PA03795-Y241	SENSOR-FLAP
SPARE PARTS	PA03795-Y245	REV-SE-SHEET
SPARE PARTS	PA03795-Y250	LOCK-LEVER
SPARE PARTS	PA03795-Y251	LOCK-LEVER
SPARE PARTS	PA03795-Y261	RV-KEEP-SPRING
SPARE PARTS	PA03795-Y263	RV-KEEP-SHEET
SPARE PARTS	PA03795-Y300	REV-FRAME
SPARE PARTS	PA03795-Y310	TOP-COVER
SPARE PARTS	PA03795-Y320	GUIDE-A
SPARE PARTS	PA03795-Y470	FLAP-S
SPARE PARTS	PA03795-Y476	FLAP-S-SPR-R
SPARE PARTS	PA03795-Y480	RV-K-SPRING-CAP
SPARE PARTS	PA03795-Y900	TEST-CHART
SPARE PARTS	PA03795-Y940	WHITE-CHART
SPARE PARTS	PA03800-D906	RV-COVER-L
SPARE PARTS	PA03800-D907	PACKAGE-ASSY
SPARE PARTS	PA03800-D908	BR-CUSHION01(M10)
SPARE PARTS	PA03800-D909	BR-CUSHION02(M10)
SPARE PARTS	PA03800-D910	TOP-BOX-ASSY
SPARE PARTS	PA03800-D916	PACKAGE-ASSY
SPARE PARTS	PA03800-D917	TOP-BOX-ASSY

SPARE PARTS	PA03800-D924	CT-HPEMP-CABLE
SPARE PARTS	PA03800-D925	DIMM
SPARE PARTS	PA03800-D931	EX-GUIDE-T-ASSY
SPARE PARTS	PA03800-D935	JUNO-MD
SPARE PARTS	PA03800-D941	JUNO CT3 L
SPARE PARTS	PA03800-D942	CSL UNIT
SPARE PARTS	PA03800-D945	JUNO-CT3
SPARE PARTS	PA03800-D948	JUNO-CT3-L
SPARE PARTS	PA03800-D950	OPT-UNIT
SPARE PARTS	PA03800-D952	CSL-UNIT
SPARE PARTS	PA03800-D960	HOPPER-UNIT
SPARE PARTS	PA03800-D961	CSL-UNIT
SPARE PARTS	PA03800-D962	STK-STOPPER-S
SPARE PARTS	PA03800-D963	STK-STOPPER-L
SPARE PARTS	PA03800-D964	STACKER-UNIT
SPARE PARTS	PA03800-D976	PIC-CUSHION(M10)
SPARE PARTS	PA03800-D981	CSL-SHEET-BRA
SPARE PARTS	PA03800-D985	EX-GUIDE-U-ASSY(M10)
SPARE PARTS	PA03800-D988	RV-COVER-L
SPARE PARTS	PA03800-D990	PIC-ROLLER-UNIT
SPARE PARTS	PA03800-D996	CSL-SHEET-KIT
SPARE PARTS	PA03800-D997	RV-COVER-L
SPARE PARTS	PA03800-F601	KEYTOP-ASSY(M10)
SPARE PARTS	PA03800-F701	HOP-GUIDE-L-ASY(M10)
SPARE PARTS	PA03800-F702	HOP-GUIDE-R-ASY(M10)
SPARE PARTS	PA03800-F720	HOP-SLIP-ASSY(M10)
SPARE PARTS	PA03800-Y303	RV-GUIDE-1(M10)
SPARE PARTS	PA03800-Y386	EX-LOCK-LEVER(M10)(J
SPARE PARTS	PA03800-Y575	SEP-SENSOR-HOLD(M10)
SPARE PARTS	PA03800-Y712	GUIDE-LEVER(M10)
SPARE PARTS	PA03800-Y751	STK-GUIDE-L(M10)
SPARE PARTS	PA03800-Y752	STK-GUIDER(M10)
SPARE PARTS	PA03800-Y760	STK-EXT2(M10)
SPARE PARTS	PA03800-Y770	STK-EXT3(M10)
SPARE PARTS	PA03805-D901	FIXED-UNIT
SPARE PARTS	PA03805-D902	FIX-SUB-UNIT
SPARE PARTS	PA03805-D930	REV-UNIT
SPARE PARTS	PA03805-D931	REV-UNIT
SPARE PARTS	PA03805-D932	REV-SUB-UNIT
SPARE PARTS	PA03805-D933	REV-SUB-UNIT
SPARE PARTS	PA03805-D950	STACKER-UNIT
SPARE PARTS	PA03805-D951	STACKER-UNIT
SPARE PARTS	PA03805-E900	CHUTER-ASSY
SPARE PARTS	PA03805-E901	CHUTER-ASSY
SPARE PARTS	PA03805-E911	GUIDE-R-ASSY
SPARE PARTS	PA03805-E930	OP-COVER-ASSY
SPARE PARTS	PA03805-E931	OP-COVER-ASSY
SPARE PARTS	PA03805-F320	BUTTON-ASSY
SPARE PARTS	PA03805-F321	BUTTON-ASSY
SPARE PARTS	PA03805-F902	ADF-MOTOR
SPARE PARTS	PA03805-F910	PAD-FRAME-UNIT
SPARE PARTS	PA03805-F911	GEAR-UNIT
SPARE PARTS	PA03805-F912	U-MOTOR
SPARE PARTS	PA03805-F921	U-GUIDE-ASSY
SPARE PARTS	PA03805-F927	CIS-CABLE
SPARE PARTS	PA03805-F930	OP-COVER-ASSY
SPARE PARTS	PA03805-F931	OP-COVER-ASSY
SPARE PARTS	PA03805-F940	BASE-COV-UNIT
SPARE PARTS	PA03805-F941	BASE-COV-UNIT
SPARE PARTS	PA03805-F951	CIS-UNIT-F
SPARE PARTS	PA03805-F952	CIS-UNIT-R
SPARE PARTS	PA03805-F960	SIDE-COVER-ASSY

SPARE PARTS	PA03805-F961	SIDE-COVER-ASSY
SPARE PARTS	PA03805-F971	U-PINCH-ROLL
SPARE PARTS	PA03805-F975	REV-KEEP-ASSY
SPARE PARTS	PA03805-F980	F-COV-ASSY
SPARE PARTS	PA03805-F981	F-COV-ASSY
SPARE PARTS	PA03805-F990	USB-COVER
SPARE PARTS	PA03805-F991	USB-COVER
SPARE PARTS	PA03805-K031	PACKAGE
SPARE PARTS	PA03805-K922	EMP-SE
SPARE PARTS	PA03805-K923	REV-SE
SPARE PARTS	PA03805-K924	FIX-SE
SPARE PARTS	PA03805-K931	CONTROL-PCA
SPARE PARTS	PA03805-K933	OP-PANEL
SPARE PARTS	PA03805-K935	F-PINCH-ROLL
SPARE PARTS	PA03805-K936	E-PINCH-ROLL
SPARE PARTS	PA03805-K938	EXIT-FG-PLATE
SPARE PARTS	PA03805-K941	RUBBER-FOOT
SPARE PARTS	PA03805-K945	PICK-BEARING
SPARE PARTS	PA03805-K962	AC ADAPTER
SPARE PARTS	PA03805-K963	WIFI-ANTENNA
SPARE PARTS	PA03805-K965	PINCH-BEARING
SPARE PARTS	PA03805-K967	R-SE-CABLE
SPARE PARTS	PA03805-K968	OP-CABLE-MAPLE
SPARE PARTS	PA03805-K972	TOP-COVER
SPARE PARTS	PA03805-K973	TOP-COVER
SPARE PARTS	PA03805-K975	FEED-ROLLER
SPARE PARTS	PA03805-K976	EXIT-ROLLER
SPARE PARTS	PA03805-K977	U-FEED-ROLLER
SPARE PARTS	PA03805-K990	GUIDE-A
SPARE PARTS	PA03805-K991	GUIDE-A
SPARE PARTS	PA03805-Y001	FIXED-FRAME
SPARE PARTS	PA03805-Y020	SW-COVER
SPARE PARTS	PA03805-Y041	UNIV-JOINT-A
SPARE PARTS	PA03805-Y200	BASE-COVER
SPARE PARTS	PA03805-Y201	BASE-COVER
SPARE PARTS	PA03805-Y210	SIDE-COVER
SPARE PARTS	PA03805-Y211	SIDE-COVER
SPARE PARTS	PA03805-Y240	LID
SPARE PARTS	PA03805-Y241	LID
SPARE PARTS	PA03805-Y250	OP-COVER
SPARE PARTS	PA03805-Y251	OP-COVER
SPARE PARTS	PA03805-Y270	WIFI-SWITCH
SPARE PARTS	PA03805-Y271	WIFI-SWITCH
SPARE PARTS	PA03805-Y280	WPS-BUTTON
SPARE PARTS	PA03805-Y281	WPS-BUTTON
SPARE PARTS	PA03805-Y312	WIFI-LED-PIPE
SPARE PARTS	PA03805-Y341	LID-SPRING
OPTION	PA03810-D20100C3	SCANNER OPTION, fi-819PRB
SPARE PARTS	PA03810-D941	BASE-UNIT
SPARE PARTS	PA03810-D942	BASE-UNIT
SPARE PARTS	PA03810-D943	FEED-ROLLER
SPARE PARTS	PA03810-D944	EXIT-ROLLER
SPARE PARTS	PA03810-D947	BASE-UNIT
SPARE PARTS	PA03810-D948	BASE-UNIT
SPARE PARTS	PA03810-D951	UPPER-UNIT
SPARE PARTS	PA03810-D952	UPPER-UNIT
SPARE PARTS	PA03810-E760	IM-BASE-UNIT
SPARE PARTS	PA03810-E801	BASE-ASSY
SPARE PARTS	PA03810-E802	BASE-ASSY
SPARE PARTS	PA03810-E803	GUIDE-P-ASSY
SPARE PARTS	PA03810-E806	OP-ASSY
SPARE PARTS	PA03810-E807	OP-ASSY

SPARE PARTS	PA03810-E808	STACKER-UNIT
SPARE PARTS	PA03810-E809	CHUTER-UNIT
SPARE PARTS	PA03810-E810	FB-TOP-COV-ASSY
SPARE PARTS	PA03810-E811	FB-MOTOR-UNIT
SPARE PARTS	PA03810-E812	DOC-COV-ASSY
SPARE PARTS	PA03810-E813	IM-BASE-UNIT
SPARE PARTS	PA03810-E814	IM-HOLDER-ASSY
SPARE PARTS	PA03810-E815	IM-PINCH-ASSY
SPARE PARTS	PA03810-E817	BASE-ASSY
SPARE PARTS	PA03810-E818	BASE-ASSY
SPARE PARTS	PA03810-E821	UPPER-ASSY
SPARE PARTS	PA03810-E822	UPPER-ASSY
SPARE PARTS	PA03810-F750	SCAN-SW-ASSY
SPARE PARTS	PA03810-F760	IM-GUIDE-UNIT
SPARE PARTS	PA03810-F780	SCAN-SW-E-ASSY
SPARE PARTS	PA03810-F810	FRONT-COV-T-A65
SPARE PARTS	PA03810-F811	FRONT-COV-T-A60
SPARE PARTS	PA03810-F812	FRONT-COV-T-A45
SPARE PARTS	PA03810-F813	FRONT-COV-T-A40
SPARE PARTS	PA03810-F814	FRONT-COV-T-A35
SPARE PARTS	PA03810-F815	FRONT-COV-T-F65
SPARE PARTS	PA03810-F816	FRONT-COV-T-F60
SPARE PARTS	PA03810-F817	FRONT-COV-T-F45
SPARE PARTS	PA03810-F818	FRONT-COV-T-F40
SPARE PARTS	PA03810-F819	FRONT-COV-T-F35
SPARE PARTS	PA03810-F905	FB-MOTOR-ASSY
SPARE PARTS	PA03810-F912	FRONT-COV-T
SPARE PARTS	PA03810-F914	FRONT-COV-T
SPARE PARTS	PA03810-F916	FRONT-COV-T
SPARE PARTS	PA03810-F922	FRONT-COV-T
SPARE PARTS	PA03810-F924	FRONT-COV-T
SPARE PARTS	PA03810-F926	FRONT-COV-T
SPARE PARTS	PA03810-F931	FULCRUM-COVER-L
SPARE PARTS	PA03810-F932	FULCRUM-COVER-R
SPARE PARTS	PA03810-F940	PICK-MOTOR-ASSY
SPARE PARTS	PA03810-F941	PICK-MOTOR
SPARE PARTS	PA03810-F942	PICK-SHAFT-ASSY
SPARE PARTS	PA03810-F943	CIS-UNIT-F
SPARE PARTS	PA03810-F944	CIS-UNIT-R
SPARE PARTS	PA03810-F945	BW-MOTOR
SPARE PARTS	PA03810-F946	GUIDE-R-ASSY
SPARE PARTS	PA03810-F947	CLUTCH
SPARE PARTS	PA03810-F948	STACKER-STOPPER
SPARE PARTS	PA03810-F949	TOP-COVER-ASSY
SPARE PARTS	PA03810-F950	IM-TOP-COVER
SPARE PARTS	PA03810-F952	IM-GUIDE-UNIT
SPARE PARTS	PA03810-F953	IM-BASE-COVER
SPARE PARTS	PA03810-F954	STACK-SUPP-F
SPARE PARTS	PA03810-F955	TOP-COVER-ASSY
SPARE PARTS	PA03810-F956	FB-BASE-COVER
SPARE PARTS	PA03810-F958	EXTEND-ASSY
SPARE PARTS	PA03810-F963	FIX-FRAME-ASSY
SPARE PARTS	PA03810-F964	FIX-FRAME-ASSY
SPARE PARTS	PA03810-F965	DOC-EXT-FB
SPARE PARTS	PA03810-F966	FRONTCOV-F-ASSY
SPARE PARTS	PA03810-F967	TOP-COVER
SPARE PARTS	PA03810-F971	RV-FRAME-ASSY
SPARE PARTS	PA03810-F981	FRONT-COV-T
SPARE PARTS	PA03810-F983	FRONT-COV-T
SPARE PARTS	PA03810-F985	FRONT-COV-T
SPARE PARTS	PA03810-F987	FRONT-COV-T
SPARE PARTS	PA03810-F991	FRONT-COV-T

SPARE PARTS	PA03810-F993	FRONT-COV-T
SPARE PARTS	PA03810-F995	FRONT-COV-T
SPARE PARTS	PA03810-F997	FRONT-COV-T
SPARE PARTS	PA03810-K915	CONTROL-PCA-A65
SPARE PARTS	PA03810-K916	CONTROL-PCA-A60
SPARE PARTS	PA03810-K917	CONTROL-PCA-A45
SPARE PARTS	PA03810-K918	CONTROL-PCA-A40
SPARE PARTS	PA03810-K919	CONTROL-PCA-A35
SPARE PARTS	PA03810-K935	CONTROL-PCA-F65
SPARE PARTS	PA03810-K936	CONTROL-PCA-F60
SPARE PARTS	PA03810-K937	CONTROL-PCA-F45
SPARE PARTS	PA03810-K938	CONTROL-PCA-F40
SPARE PARTS	PA03810-K939	CONTROL-PCA-F35
SPARE PARTS	PA03810-K940	US-SENSOR-FX
SPARE PARTS	PA03810-K941	PICK-BEARING2
SPARE PARTS	PA03810-K943	ADF-MOTOR
SPARE PARTS	PA03810-K944	F-PINCH-ROLL
SPARE PARTS	PA03810-K945	E-PINCH-ROLL
SPARE PARTS	PA03810-K946	PINCH-BEARING
SPARE PARTS	PA03810-K947	PANEL-PCA-H
SPARE PARTS	PA03810-K948	PANEL-PCA-L
SPARE PARTS	PA03810-K949	PANEL-PCA-E
SPARE PARTS	PA03810-K951	LCD
SPARE PARTS	PA03810-K953	CONTROL-PCA-AHP
SPARE PARTS	PA03810-K955	CONTROL-PCA-ALP
SPARE PARTS	PA03810-K957	CONTROL-PCA-AEP
SPARE PARTS	PA03810-K959	CONTROL-PCA-AUP
SPARE PARTS	PA03810-K960	AC-ADAPTER
SPARE PARTS	PA03810-K961	CONTROL-PCA-FH
SPARE PARTS	PA03810-K962	CONTROL-PCA-FL
SPARE PARTS	PA03810-K963	CONTROL-PCA-FE
SPARE PARTS	PA03810-K964	CONTROL-PCA-FU
SPARE PARTS	PA03810-K965	CR-CABLE
SPARE PARTS	PA03810-K967	IMP-CT-LY6
SPARE PARTS	PA03810-K968	TENSION-JIG-PIC
SPARE PARTS	PA03810-K969	TENSION-JIG-ADF
SPARE PARTS	PA03810-K970	IMP-JNT
SPARE PARTS	PA03810-K971	PR-HARNESS
SPARE PARTS	PA03810-K972	CIS-R-CABLE-LY6
SPARE PARTS	PA03810-K974	US-SENSOR-FX-E
SPARE PARTS	PA03810-K980	ADJ-CHART-KIT3
SPARE PARTS	PA03810-K981	PANEL-PCA-65
SPARE PARTS	PA03810-K982	PANEL-PCA-60
SPARE PARTS	PA03810-K983	PANEL-PCA-45
SPARE PARTS	PA03810-K984	PANEL-PCA-40
SPARE PARTS	PA03810-K985	PANEL-PCA-35
SPARE PARTS	PA03810-K990	TEST-CHART-NO78
SPARE PARTS	PA03810-Y111	SG-CAM
SPARE PARTS	PA03810-Y114	SG-GEAR
SPARE PARTS	PA03810-Y123	BEARING-COLLAR
SPARE PARTS	PA03810-Y125	F-PULLEY-GEAR
SPARE PARTS	PA03810-Y126	REDU-PULLEY
SPARE PARTS	PA03810-Y144	P-PULLEY-GEAR
SPARE PARTS	PA03810-Y160	PICK-SHAFT-L6
SPARE PARTS	PA03810-Y164	PICK-GEAR-L6
SPARE PARTS	PA03810-Y204	FEED-GEAR
SPARE PARTS	PA03810-Y212	E-RING-2R5
SPARE PARTS	PA03810-Y222	EMPTY-ARM-1
SPARE PARTS	PA03810-Y224	EMPTY-ARM-2
SPARE PARTS	PA03810-Y263	FEED-SPRING
SPARE PARTS	PA03810-Y265	UNIV-JOINT-A
SPARE PARTS	PA03810-Y266	UNIV-JOINT-B

SPARE PARTS	PA03810-Y351	DOC-STOPPER
SPARE PARTS	PA03810-Y361	CR-STOPPER
SPARE PARTS	PA03810-Y401	DOC-SLIDER1-L6
SPARE PARTS	PA03810-Y411	DOC-SLIDER2-L6
SPARE PARTS	PA03810-Y720	FRONT-COV-F
SPARE PARTS	PA03810-Y730	OP-COVER
SPARE PARTS	PA03810-Y740	SWITCH
SPARE PARTS	PA03810-Y760	LCD-PANEL
SPARE PARTS	PA03810-Y794	OP-FILTER-E
SPARE PARTS	PA03810-Y900	OP-FILTER-E
SPARE PARTS	PA03810-Y910	SWITCH-E
SPARE PARTS	PA03811-0917	OUTER-BOX
SPARE PARTS	PA03811-K924	FRONT CIS UNIT
SPARE PARTS	PA03811-K930	CONTROL PCA 20
SPARE PARTS	PA03811-K931	CONTROL PCA 25
SPARE PARTS	PA03811-K932	CONTROL PCA 30
SPARE PARTS	PA03811-K943	BACK CIS UNIT
SPARE PARTS	PA03811-K950	TOP COVER UNIT
SPARE PARTS	PA03811-K951	TOP COVER UNIT
SPARE PARTS	PA03820-D973	FIXED-UNIT-U
SPARE PARTS	PA03820-D977	TOP-COV-U-ASSY
SPARE PARTS	PA03820-D978	TOP-COV-U-ASSY
SPARE PARTS	PA03820-D979	TOP-COV-U-ASSY
SPARE PARTS	PA03820-E979	CHUT-U-ASSY(H
SPARE PARTS	PA03820-E980	CHUT-U-ASSY
SPARE PARTS	PA03820-E987	CONTROL-U-PCA
SPARE PARTS	PA03820-E988	CONTROL-U-PCA
SPARE PARTS	PA03820-K071	PACKAGE
SPARE PARTS	PA03820-K401	PACKAGE-M
SPARE PARTS	PA03820-K973	OP-PCA
SPARE PARTS	PA03820-K980	SIDE-COVER-R
SPARE PARTS	PA03820-K981	SIDE-COVER-R
SPARE PARTS	PA03836-D910	REVOLVE-UNIT
SPARE PARTS	PA03836-D930	FIXED-UNIT
SPARE PARTS	PA03836-E900	TOP-COVER
SPARE PARTS	PA03836-E910	CIS-UNIT-B
SPARE PARTS	PA03836-E920	BR-ROLLER-ASSY
SPARE PARTS	PA03836-E930	FIX-SUB-UNIT
SPARE PARTS	PA03836-E935	MOTOR-UNIT
SPARE PARTS	PA03836-E940	GEAR-BOX-ASSY
SPARE PARTS	PA03836-E945	CIS-UNIT-F
SPARE PARTS	PA03836-E950	PICK-ROLLER-ASY
SPARE PARTS	PA03836-E955	CONTROL-PCA
SPARE PARTS	PA03836-E960	GUIDE-A
SPARE PARTS	PA03836-E965	STACKER-ASSY
SPARE PARTS	PA03836-E970	STACKER-EXTEND
SPARE PARTS	PA03836-E980	SIDE-COVER-R
SPARE PARTS	PA03836-E990	SIDE-COVER-L
SPARE PARTS	PA03836-K021	PACKAGE
SPARE PARTS	PA03836-K805	FG-HARNESS
SPARE PARTS	PA03836-K815	JNT-PCA
SPARE PARTS	PA03836-K825	LCD
SPARE PARTS	PA03836-Y001	FIXED-FRAME
SPARE PARTS	PA03836-Y125	POW-BUTTON
SPARE PARTS	PA03836-Y135	FG-SPRING-LCD
SPARE PARTS	PA03836-Y138	FG-SHEET-LCD
SPARE PARTS	PA03836-Y141	LCD-CUSHION
SPARE PARTS	PA03841-K900	CONTROL PCA
SPARE PARTS	PA03841-K910	IMG SENSOR ASSY
SPARE PARTS	PA03841-K920	TOP COV ASSY
SPARE PARTS	PA03950-0153	MOTOR
SPARE PARTS	PA03950-0228	SENSOR SF3

SPARE PARTS	PA03950-0769	CIS
SPARE PARTS	PA03950-0830	CIS
SPARE PARTS	PA03950-0856	ABSORBER
SPARE PARTS	PA03950-0882	COVER-SET-W
SPARE PARTS	PA03950-0883	COVER-SET-B
SPARE PARTS	PA03950-0897	MOTOR
SPARE PARTS	PA03950-0898	MOTOR
SPARE PARTS	PA03950-0980	CIS
SPARE PARTS	PA03951-0224	CR BELT
SPARE PARTS	PA03951-0225	BELT
SPARE PARTS	PA03951-0313	BELT
SPARE PARTS	PA03951-0610	C SCREW
SPARE PARTS	PA03951-0815	GT BELT
SPARE PARTS	PA03951-0838	MAGNETIC CATCH
SPARE PARTS	PA03951-0842	O RING
SPARE PARTS	PA03951-0843	O RING
SPARE PARTS	PA03951-0932	BELT
SPARE PARTS	PA03951-0955	PIC-BELT
SPARE PARTS	PA03951-0956	BELT
SPARE PARTS	PA03951-0957	BELT
SPARE PARTS	PA03951-1020	O-RING
SPARE PARTS	PA03951-1030	BELT
SPARE PARTS	PA03951-1133	EXIT-BELT-1
SPARE PARTS	PA03951-1143	GND CLAMP
SPARE PARTS	PA03951-1147	PUSH RIVET
SPARE PARTS	PA03951-1240	NUT
SPARE PARTS	PA03951-1631	TORQUE LIMITTER
SPARE PARTS	PA03951-1671	MOTOR-BELT
SPARE PARTS	PA03951-1672	FEED-BELT
SPARE PARTS	PA03951-1741	BELT
SPARE PARTS	PA03951-1742	BELT
SPARE PARTS	PA03951-1945	TORQUE-LIMITER
SPARE PARTS	PA03951-2210	THUMB-SCREW
SPARE PARTS	PA03951-2593	TORQUE-LIMITER
SPARE PARTS	PA03951-2621	BELT
SPARE PARTS	PA43201-K051	ACROBAT8 FOR EU
SPARE PARTS	PA43201-K052	ACROBAT8 FOR N.A.
SPARE PARTS	PA43201-K055	ACROBAT8 FOR FCPA
OPTION	PA43403-A264	SOFTWARE, SCANNER CONTROL SDK V2.1
SPARE PARTS	PA43404-A820	Scan to DocuWorks
SPARE PARTS	PA43404-A821	Scan to DocuWorks 5 Licenses
SPARE PARTS	PA43404-A822	Scan to DocuWorks 10 Licenses
SPARE PARTS	PA43404-A823	Scan to DocuWorks 20 Licenses
SPARE PARTS	PA43404-A824	Scan to DocuWorks 50 Licenses
SPARE PARTS	PA43404-A825	Scan to DocuWorks 100 Licenses
SPARE PARTS	PA46009-0009	SENSOR
SPARE PARTS	PA49001-0377	SWITCH
SPARE PARTS	PA49001-0458	SWITCH
SPARE PARTS	PA53003-0507	CORE
SPARE PARTS	PA55001-0042	THERMISTOR
SPARE PARTS	PA61001-0142	USB CABLE
SPARE PARTS	PA61001-0163	USB CABLE P
SPARE PARTS	PA61001-0164	USB CABLE M
SPARE PARTS	PA61001-0169	USB CABLE
SPARE PARTS	PA61001-0171	USB CABLE
SPARE PARTS	PA61001-0181	USB-CABLE
SPARE PARTS	PA63082-1831	AC CORDSET U
SPARE PARTS	PA63083-1831	AC CORDSET E
SPARE PARTS	PA63085-2001	AC CORDSET E
SPARE PARTS	PA63086-2001	AC CORDSET U
SPARE PARTS	PA63088-2001	AC CORDSET C
SPARE PARTS	PA63091-3001	AC CORD SET

SPARE PARTS	PA63101-3001	AC CORDSET UK
SPARE PARTS	PA63112-2001	AC CABLE E
SPARE PARTS	PA63113-2001	AC CABLE U
SPARE PARTS	PA63116-2001	AC CABLE U
SPARE PARTS	PA63117-2001	AC CABLE E
SPARE PARTS	PA63118-2001	AC CABLE UK
SPARE PARTS	PA63119-2001	AC CABLE UK
SPARE PARTS	PA63143-1831	AC CABLE C
SPARE PARTS	PA70002-0622	IMPRINTER CABLE
SPARE PARTS	PA70002-0627	FPC CABLE
SPARE PARTS	PA70002-0927	FG HARNESS 2
SPARE PARTS	PA70002-0928	CR CABLE
SPARE PARTS	PA70002-1190	IMP CABLE
SPARE PARTS	PA70002-1404	FB MT HARNESS
SPARE PARTS	PA70002-1405	HP SE HARNESS
SPARE PARTS	PA70002-1406	SW HARNESS
SPARE PARTS	PA70002-1854	CARRIER CABLE
SPARE PARTS	PA70002-2175	PRE-IMPRINTER CABLE
SPARE PARTS	PA70002-2211	FEED MOTOR CABLE
SPARE PARTS	PA70002-2219	FEED MOTOR CABLE 2
SPARE PARTS	PA70002-2221	BRAKE CABLE
SPARE PARTS	PA70002-2222	HP-EMP CABLE
SPARE PARTS	PA70002-2224	CT-POW CABLE
SPARE PARTS	PA70002-2243	SEPARATION MOTOR CABLE
SPARE PARTS	PA70002-2249	MD2-INVERTER CABLE
SPARE PARTS	PA70002-2250	DF SENSOR CABLE
SPARE PARTS	PA70002-2251	MD2-OUTSIDE CABLE
SPARE PARTS	PA70002-2252	PR CABLE(M10)
SPARE PARTS	PA70002-2253	STACKER SENSOR CABLE R
SPARE PARTS	PA70002-2254	STACKER SENSOR CABLE L
SPARE PARTS	PA70002-2255	MD2-OUTSIDE MOTOR CABLE
SPARE PARTS	PA70002-2256	MD2-INSIDE CABLE
SPARE PARTS	PA70002-2257	ENCODER FG CABLE
SPARE PARTS	PA70002-3535	CONSOLE CABLE
SPARE PARTS	PA70002-3536	CONSOLE CABLE
SPARE PARTS	PA70002-3538	CCD CABLE B
SPARE PARTS	PA70002-3539	CT-IMPINTER CABLE
SPARE PARTS	PA70002-3540	CT-MD2 CABLE S1
SPARE PARTS	PA70002-3541	CT-MD2 CABLE S2
SPARE PARTS	PA70002-3542	CT-MD2 CABLE POW
SPARE PARTS	PA70002-3543	FAN CABLE
SPARE PARTS	PA70002-3544	RED TP CABLE
SPARE PARTS	PA70002-3545	CT-SENSOR CABLE
SPARE PARTS	PA70002-3546	CT-INVERTER CABLE
SPARE PARTS	PA70002-3547	CT-REJECT CABLE
SPARE PARTS	PA70002-3548	HOPPER MOTOR CABLE
SPARE PARTS	PA70002-3549	CT-HPSE CABLE
SPARE PARTS	PA70002-3550	INTERLOCK CABLE 1
SPARE PARTS	PA70002-3551	IL CABLE 2
SPARE PARTS	PA70002-3552	MD2-DF CABLE
SPARE PARTS	PA70002-4423	CONSOL CABLE
SPARE PARTS	PA70002-5352	FAN CABLE
SPARE PARTS	PA70002-5354	LL CABLE
SPARE PARTS	PA70002-5356	CT POW_CABLE
SPARE PARTS	PA70002-5359	SOFT SW CABLE
SPARE PARTS	PA70002-5362	CT L MT CABLE
SPARE PARTS	PA70002-5364	CCD B CABLE
SPARE PARTS	PA70002-5365	CT LED CABLE
SPARE PARTS	PA70002-5366	CT R SE CABLE
SPARE PARTS	PA70002-5367	CT HPMP_CABLE
SPARE PARTS	PA70002-5368	CT R MT CABLE
SPARE PARTS	PA70002-5369	CT L SE CABLE

SPARE PARTS	PA70002-5381	EXIT SE CABLE
SPARE PARTS	PA70002-5383	MD R SE CABLE
SPARE PARTS	PA70002-5384	PICK MT CABLE
SPARE PARTS	PA70002-5385	MD BACK MT CBL
SPARE PARTS	PA70002-5386	LED_CABLE
SPARE PARTS	PA70002-5387	PICK SE CABLE
SPARE PARTS	PA70002-5388	SE FRM CABLE
SPARE PARTS	PA70002-5389	MD FR MT CABLE
SPARE PARTS	PA70002-5390	MD BACK SE CBL
SPARE PARTS	PA70002-5393	MD L SE CABLE
SPARE PARTS	PA70002-5394	IMP F CABLE
SPARE PARTS	PA70002-5395	IMP B CABLE
SPARE PARTS	PA70002-5401	PICK_FG_CABLE
SPARE PARTS	PA70002-5402	USSE FG CABLE
SPARE PARTS	PA70002-5403	FIX_RV_FG_CABLE
SPARE PARTS	PA70002-5512	MD CABLE
SPARE PARTS	PA70002-5513	CT RV CABLE
SPARE PARTS	PA70002-5771	CIS CABLE REV
SPARE PARTS	PA70002-5956	OP CABLE
SPARE PARTS	PA70002-5957	CIS CABLE
SPARE PARTS	PA70002-6004	LAN CABLE
SPARE PARTS	PA70002-6257	CCD HARNESS FB4
SPARE PARTS	PA70002-6767	REV CABLE 2
SPARE PARTS	PA70002-6814	CIS-CABLE-F
SPARE PARTS	PA70002-6815	CCD-HARNESS-F
SPARE PARTS	PA70002-6911	US-FIX-HARNESS
SPARE PARTS	PA70002-6912	US-REV-HARNESS
SPARE PARTS	PA70002-6914	OP-HARENSS
SPARE PARTS	PA70002-6915	SE-HARNESS
SPARE PARTS	PA70002-6916	FG-HARNESS-1
SPARE PARTS	PA70002-6967	CIS-CABLE-R
SPARE PARTS	PA70002-6997	BS-HARNESS-5
SPARE PARTS	PA70002-7001	LED-HARNESS-FB
SPARE PARTS	PA70002-7051	IR-FFC-CABLE
SPARE PARTS	PA70002-7242	FX-HARNESS-F5
SPARE PARTS	PA70002-7360	SE-HARNESS-B5
SPARE PARTS	PA70002-7421	OP-CABLE
SPARE PARTS	PA70002-7577	SE-HARNESS
SPARE PARTS	PA70002-7578	USB-T-CABLE
SPARE PARTS	PA70002-7579	USB-S-CABLE
SPARE PARTS	PA70002-7580	DC-CABLE
SPARE PARTS	PA70002-7581	TSC-CABLE
SPARE PARTS	PA70002-7739	BKL-CABLE
SPARE PARTS	PA70002-7791	US-EMP-MIC-HNS
SPARE PARTS	PA70002-7792	CCD-POW-R-HNS
SPARE PARTS	PA70002-7793	CCD-CLK-R-HNS
SPARE PARTS	PA70002-7794	OP-LCD-HARNESS
SPARE PARTS	PA70002-7795	CCD-POW-F-HNS
SPARE PARTS	PA70002-7796	CCD-CLK-F-HNS
SPARE PARTS	PA70002-7797	COV-US-HNS
SPARE PARTS	PA70002-7800	LED-HNS-F-JOINT
SPARE PARTS	PA70002-7903	OP-HARNESS-N
SPARE PARTS	PA70002-7920	SE-HARNESS-B5E
SPARE PARTS	PA70002-7921	CCD-HARNESS-F5E
SPARE PARTS	PA70002-7922	BS-HARNESS-B5E
SPARE PARTS	PA70002-7985	CCD-HARNESS-B
SPARE PARTS	PA70002-8136	LCD-CABLE
SPARE PARTS	PA70002-8233	BS-HARNESS-B5L
SPARE PARTS	PA70002-8278	ADF-OP-LED-HNS
SPARE PARTS	PA70002-8279	FB-LED-MIC-HNS
SPARE PARTS	PA70002-8280	LED-MIC-J-HNS
SPARE PARTS	PA70002-8281	US-PIC-MIC-HNS

SPARE PARTS	PA70002-8282	CCD-POW-R-HNS
SPARE PARTS	PA70002-8287	ME3-COV-US-HNS
SPARE PARTS	PA70002-8288	LED-HNS-F-JOINT
SPARE PARTS	PA70002-8289	PIC-ARM-MT-JOIN
SPARE PARTS	PA70002-8290	EMP-SEPA-HNS
SPARE PARTS	PA70002-8297	FB-LED-HNS-JNT
SPARE PARTS	PA70002-8301	SEPA-S-JOIN-HNS
SPARE PARTS	PA70002-8324	FB-OP-JNT-HNS
SPARE PARTS	PA70002-8376	OP-HARNESS
SPARE PARTS	PA70002-8519	IF-JNT-CABLE
SPARE PARTS	PA70002-8728	SEP-CHUSW-HNS
SPARE PARTS	PA70002-8729	SE-HARENESS
SPARE PARTS	PA70002-8932	US-FIX-HNS-2
SPARE PARTS	PA70002-9128	JNT-CABLE
SPARE PARTS	PA70002-9129	CIS-CABLE-R
SPARE PARTS	PA70002-9168	F-EXIT-CBL-KMY
SPARE PARTS	PA70002-9169	CV-OPEN-CBL-KMY
SPARE PARTS	PA70002-9236	OP-LCD-CBL-LYX6
SPARE PARTS	PA70002-9242	DC-MT-HNS-LYNX6
SPARE PARTS	PA70002-9255	CIS-F-CBL-LYNX6
SPARE PARTS	PA70002-9258	US-FIX-HNS-LY6H
SPARE PARTS	PA70002-9259	US-FIX-HNS-LY6E
SPARE PARTS	PA70002-9262	RV-SE-HNS-LYX6H
SPARE PARTS	PA70002-9263	RV-SE-HNS-LYX6E
SPARE PARTS	PA70002-9278	CCD-HARNESS-F5E
SPARE PARTS	PA70002-9294	CHUTSW-HNS
SPARE PARTS	PA70002-9388	COV-CHUSW-HNS
SPARE PARTS	PA70002-9497	BS-HARNESS-B5LR
SPARE PARTS	PA70002-9557	CCD-HNS-F5ER
SPARE PARTS	PA70002-9952	SEP-HNS-MERC4
SPARE PARTS	PA82900-0010	FG CLAMP
SPARE PARTS	PA82900-0012	FG CLAMP
SPARE PARTS	PA82900-0014	FG CLAMP
SPARE PARTS	PA82900-0403	CR MOTOR
SPARE PARTS	PA83950-0352	CORE
SPARE PARTS	PA83950-0356	MINI CLAMP
SPARE PARTS	PA83950-0626	MAGNET CATCH
SPARE PARTS	PA83950-1564	CORE
SPARE PARTS	PA83951-0222	CABLE CLAMP
SPARE PARTS	PA83951-1460	CLAMP
SPARE PARTS	PA83951-1461	CLAMP
SPARE PARTS	PA83951-1462	CLAMP
SPARE PARTS	PA83951-1464	CLAMP
SPARE PARTS	PA83951-1510	THUMB SCREW
SPARE PARTS	PA83951-1991	REPEAT TIE
SPARE PARTS	PA83951-2900	CLAMP
SPARE PARTS	PA83951-2901	CLAMP
SPARE PARTS	PA83951-3600	FREE BUSH
SPARE PARTS	PA83951-3720	PRECOATED SCREW
SPARE PARTS	PA83951-3728	PRECOATED SCREW
SPARE PARTS	PA83951-3785	COAT TP SCREW
SPARE PARTS	PA83951-5091	FG-CLAMP
SPARE PARTS	PA83952-0309	NYLON RIVET
SPARE PARTS	PA83952-1103	MINI CLAMP
SPARE PARTS	PA83952-1104	MINI-CLAMP
SPARE PARTS	PA83952-1202	CLAMP
SPARE PARTS	PA83952-2616	PT SCREW
SPARE PARTS	PA83952-2630	PT SCREW
SPARE PARTS	PA83952-2632	PT SCREW
SPARE PARTS	PA83952-2636	PT SCREW
SPARE PARTS	PA83952-2638	PT SCREW
SPARE PARTS	PA83952-4402	CLAMP

SPARE PARTS	PA83952-4603	E-RING
SPARE PARTS	PA83952-4604	E-RING
SPARE PARTS	PA83952-4605	E-RING
SPARE PARTS	PA83952-4606	E-RING
SPARE PARTS	PA83952-4607	E-RING
SPARE PARTS	PA83952-4608	E-RING
SPARE PARTS	PA83952-5032	PT SCREW
SPARE PARTS	PA83952-5038	PT SCREW
SPARE PARTS	PA83952-5040	PT SCREW
SPARE PARTS	PA83952-7715	ABSORBER
SPARE PARTS	PA83953-0561	BEARING
SPARE PARTS	PA83953-4262	BEARING
SPARE PARTS	PA83953-4263	BEARING
SPARE PARTS	PA83957-0228	SCREW
SPARE PARTS	PA93005-Y552	LABEL IMP
SPARE PARTS	PA93005-Y553	LABEL IMP SIZE
SPARE PARTS	PA93005-Y558	LABEL IMP 2
SPARE PARTS	PA93008-Y497	ADJUST CHART
SPARE PARTS	PA93010-Y621	CLEANING GUIDE
SPARE PARTS	PA93010-Y790	ADJUST CHART A4
SPARE PARTS	PA93013-Y171	BATTERY-LABEL3
SPARE PARTS	PA93013-Y767	ACC-TRAY
SPARE PARTS	PA93014-Y363	FA-LABEL
SPARE PARTS	PA93015-Y036	US-CHART-A6
SPARE PARTS	PA93015-Y271	BATTERY-LABEL
SPARE PARTS	PA93015-Y272	BATTERY-LABEL
SPARE PARTS	PA97300-G051	OUTER BOX L3AH C
SPARE PARTS	PA97300-G052	OUTER BOX L3AH LC
SPARE PARTS	PA97300-G055	OUTER BOX L3FH C
SPARE PARTS	PA97301-K132	FULL PACKAGING MATERIALS
SPARE PARTS	PA97301-K481	PACKAGE L3
SPARE PARTS	PA97301-K482	PACKAGE L3 L
SPARE PARTS	PA97301-K483	PACKAGE L3AHT
SPARE PARTS	PA97301-K487	PACKAGE L3FHT
SPARE PARTS	PA97301-K491	PACKAGE
SPARE PARTS	PA97301-K501	PACKAGE L3 C
SPARE PARTS	PA97301-K502	PACKAGE L3 LC
SPARE PARTS	PA97301-K505	PACKAGE L3 C
SPARE PARTS	PA97301-K506	PACKAGE L3 LC
SPARE PARTS	PA97301-K826	PACKAGE FLA25
SPARE PARTS	PA97301-K956	FULL PACKING
SPARE PARTS	PA97301-Y230	CUSHION L
SPARE PARTS	PA97301-Y231	CUSHION R
SPARE PARTS	PA97301-Y848	ACCESSORY TRAY
SPARE PARTS	PA97301-Y850	LOWER BOX
SPARE PARTS	PA97301-Y910	OUTER BOX
SPARE PARTS	PA97302-K601	PACKAGE-SR
SPARE PARTS	PA97302-K901	PACKAGE
SPARE PARTS	PA97302-Y481	OUTER BOX L3AH
SPARE PARTS	PA97302-Y482	OUTER BOX L3AH L
SPARE PARTS	PA97302-Y485	OUTER BOX L3FH
SPARE PARTS	PA97302-Y486	OUTER BOX L3FH L
SPARE PARTS	PA97302-Y491	OUTER BOX I
SPARE PARTS	PA97302-Y511	CUSHION TL IMP
SPARE PARTS	PA97302-Y512	CUSHION TR IMP
SPARE PARTS	PA97302-Y513	CUSHION BL IMP
SPARE PARTS	PA97302-Y514	CUSHION BR IMP
SPARE PARTS	PA97303-K261	PACKAGE L4FH
SPARE PARTS	PA97303-K706	PACKAGE-L5-AEL
SPARE PARTS	PA97303-K806	PACKAGE-L5-FEL
SPARE PARTS	PA97303-Y151	OUTER BOX
SPARE PARTS	PA97303-Y484	BTM PLATE

SPARE PARTS	PA97303-Y485	ACC TRAY
SPARE PARTS	PA97303-Y519	CARTON
SPARE PARTS	PA97303-Y520	CUSHION L
SPARE PARTS	PA97303-Y521	CUSHION R
SPARE PARTS	PA97303-Y563	OUTER BOX
SPARE PARTS	PA97303-Y564	OUTER BOX
SPARE PARTS	PA97303-Y565	OUTER BOX
SPARE PARTS	PA97303-Y566	OUTER BOX
SPARE PARTS	PA97303-Y747	BT BOARD
SPARE PARTS	PA97303-Y910	CUSHION T
SPARE PARTS	PA97304-K003	PACKAGE-H
SPARE PARTS	PA97304-K012	PACKAGE-L
SPARE PARTS	PA97304-K032	PACKAGE-B-IMP
SPARE PARTS	PA97304-K035	PACKAGE-B-IMP-G
SPARE PARTS	PA97304-K403	PACKAGE-ADF3
SPARE PARTS	PA97304-K412	PACKAGE-ME3
SPARE PARTS	PA97304-K422	PACKAGE-ME3
SPARE PARTS	PA97304-K433	PACKAGE-IM
SPARE PARTS	PA97304-K713	PACKAGE-CH
SPARE PARTS	PA97304-Y398	ACC-TRAY
SPARE PARTS	PA97304-Y399	PLASTIC-BAG
SPARE PARTS	PA97304-Y492	PLASTIC BAG
SPARE PARTS	PA97304-Y493	PLASTIC BAG
SPARE PARTS	PA97304-Y520	CUSHION BL
SPARE PARTS	PA97304-Y521	CUSHION BR
SPARE PARTS	PA97304-Y522	CUSHION TL
SPARE PARTS	PA97304-Y523	CUSHION TR
SPARE PARTS	PA97304-Y524	CUSHION CTR
SPARE PARTS	PA97304-Y525	CUSHION BL
SPARE PARTS	PA97304-Y526	CUSHION BR
SPARE PARTS	PA97304-Y527	CUSHION TL
SPARE PARTS	PA97304-Y528	CUSHION TR
SPARE PARTS	PA97304-Y529	CUSHION
SPARE PARTS	PA97304-Y575	CONTAINER BOX BOTTOM
SPARE PARTS	PA97304-Y620	CUSHION-BL
SPARE PARTS	PA97304-Y621	CUSHION-BR
SPARE PARTS	PA97304-Y622	CUSHION-TL
SPARE PARTS	PA97304-Y623	CUSHION-TR
SPARE PARTS	PA97304-Y701	OUTER-BOX
SPARE PARTS	PA97304-Y756	OUTER-BOX-L5AE
SPARE PARTS	PA97304-Y766	OUTER-BOX-L5FEL
SPARE PARTS	PA97304-Y781	CUSHION L ADF
SPARE PARTS	PA97304-Y782	CUSHION R ADF
SPARE PARTS	PA97304-Y791	CUSHION L FB
SPARE PARTS	PA97304-Y792	CUSHION R FB
SPARE PARTS	PA97304-Y801	CUSHION L IMP
SPARE PARTS	PA97304-Y802	CUSHION R IMP
SPARE PARTS	PA97304-Y833	BTM BOX
SPARE PARTS	PA97304-Y970	CUSHION-T1
SPARE PARTS	PA97304-Y971	CUSHION-B1
SPARE PARTS	PA97304-Y972	CUSHION-B2
SPARE PARTS	PA97304-Y973	CUSHION-B3
SPARE PARTS	PA97304-Y974	CUSHION-T2
SPARE PARTS	PA97305-K087	PACKAGE
SPARE PARTS	PA97305-K088	PACKAGE
SPARE PARTS	PA97305-K121	PACKAGE-ASSY
SPARE PARTS	PA97305-K137	PACKAGE-A4-FB
SPARE PARTS	PA97305-K140	PACKAGE-L6-A
SPARE PARTS	PA97305-K141	PACKAGE-L6-A-M
SPARE PARTS	PA97305-K143	PACKAGE-L6-A
SPARE PARTS	PA97305-K145	PACKAGE-L6-F
SPARE PARTS	PA97305-K146	PACKAGE-L6-IMP

SPARE PARTS	PA97305-K148	PACKAGE-ADF3-LA
SPARE PARTS	PA97305-Y021	OUTER BOX L4FH
SPARE PARTS	PA97305-Y141	OUTER BOX
SPARE PARTS	PA97305-Y182	TRAY
SPARE PARTS	PA97305-Y185	TRAY T
SPARE PARTS	PA97305-Y203	BUTTON-COVER
SPARE PARTS	PA97305-Y281	COVER-SHEET-L
SPARE PARTS	PA97305-Y423	B-CUSHION-L
SPARE PARTS	PA97305-Y424	B-CUSHION-R
SPARE PARTS	PA97305-Y425	T-CUSHION-L
SPARE PARTS	PA97305-Y426	T-CUSHION-R
SPARE PARTS	PA97305-Y427	ACC-BOX
SPARE PARTS	PA97305-Y432	OUTER-BOX
SPARE PARTS	PA97305-Y521	OUTER-BOX(M10)(H)
SPARE PARTS	PA97305-Y611	PACKAGE-BOX(M10)(H)
SPARE PARTS	PA97305-Y713	OUTER-BOX-ATL-H
SPARE PARTS	PA97305-Y714	OUTER-BOX-ATL-L
SPARE PARTS	PA97305-Y733	OUTER-BOX-B-IMP
SPARE PARTS	PA97305-Y751	ATL-CUSHION-T
SPARE PARTS	PA97305-Y752	ATL-CUSHION-B
SPARE PARTS	PA97305-Y771	A-IMB-CUSHION-T
SPARE PARTS	PA97305-Y772	A-IMB-CUSHION-B
SPARE PARTS	PA97305-Y781	COVER-SHEET-ATL
SPARE PARTS	PA97305-Y854	CUSHION-B-A4-FB
SPARE PARTS	PA97305-Y855	CUSHION-T-A4-FB
SPARE PARTS	PA97305-Y881	CUSHION-BL
SPARE PARTS	PA97305-Y882	CUSHION-BR
SPARE PARTS	PA97305-Y883	CUSHION-TL
SPARE PARTS	PA97305-Y884	CUSHION-TR
SPARE PARTS	PA97305-Y891	ACC-TRAY-M3
SPARE PARTS	PA97305-Y925	OUTER-BOX-A4-FB
SPARE PARTS	PA97306-Y094	OUTER-BOX
SPARE PARTS	PA97306-Y173	OUTER-BOX-ADF3
SPARE PARTS	PA97306-Y183	OUTER-BOX-ME3
SPARE PARTS	PA97306-Y184	OUTER-BOX-ME3
SPARE PARTS	PA97306-Y193	OUTER-BOX-IM
SPARE PARTS	PA97306-Y231	CUSHION-ADF3-T
SPARE PARTS	PA97306-Y232	CUSHION-ADF3-B
SPARE PARTS	PA97306-Y241	CUSHION-ME3-T
SPARE PARTS	PA97306-Y242	CUSHION-ME3-B
SPARE PARTS	PA97306-Y251	IM-CUSHION-T
SPARE PARTS	PA97306-Y252	IM-CUSHION-B
SPARE PARTS	PA97306-Y287	OUTER-BOX
SPARE PARTS	PA97306-Y411	APPENDED-BOX-A
SPARE PARTS	PA97306-Y412	APPENDED-PAT1-A
SPARE PARTS	PA97306-Y413	APPENDED-PAT2-A
SPARE PARTS	PA97306-Y414	APPENDED-PAT3-A
SPARE PARTS	PA97306-Y690	CUSHION-BL
SPARE PARTS	PA97306-Y691	CUSHION-BR
SPARE PARTS	PA97306-Y692	CUSHION-TL
SPARE PARTS	PA97306-Y693	CUSHION-TR
SPARE PARTS	PA97306-Y813	OUTER-BOX-CH
SPARE PARTS	PA97307-Y001	OUTER-BOX
SPARE PARTS	PA97307-Y032	OUTER-BOX
SPARE PARTS	PA97307-Y040	CUSHION-L
SPARE PARTS	PA97307-Y041	CUSHION-R
SPARE PARTS	PA97307-Y222	TOP-BOX
SPARE PARTS	PA97307-Y223	TOP-BOX
SPARE PARTS	PA97307-Y307	OUTER-BOX
SPARE PARTS	PA97307-Y360	ACC-TRAY
SPARE PARTS	PA97307-Y361	CIS-CUSHION
SPARE PARTS	PA97307-Y366	PAD-CUSHION(M10)(S)

SPARE PARTS	PA97307-Y386	PAD-CUSHION
SPARE PARTS	PA97307-Y451	PACKAGE-BOX
SPARE PARTS	PA97307-Y454	PACKAGE-BOX
SPARE PARTS	PA97307-Y457	PACKAGE-BOX
SPARE PARTS	PA97307-Y481	PACKAGE-BOX
SPARE PARTS	PA97307-Y482	PACKAGE-BOX
SPARE PARTS	PA97307-Y523	OUTER-BOX
SPARE PARTS	PA97307-Y531	CUSHION-BL
SPARE PARTS	PA97307-Y532	CUSHION-BR
SPARE PARTS	PA97307-Y533	CUSHION-TL
SPARE PARTS	PA97307-Y534	CUSHION-TR
SPARE PARTS	PA97307-Y540	ACC-TRAY
SPARE PARTS	PA97307-Y545	CUSHION-L-ADF
SPARE PARTS	PA97307-Y546	CUSHION-R-ADF
SPARE PARTS	PA97307-Y559	OUTER-BOX-L6A
SPARE PARTS	PA97307-Y565	OUTER-BOX-L6F
SPARE PARTS	PA97307-Y570	CUSHION-L-FB
SPARE PARTS	PA97307-Y571	CUSHION-R-FB
SPARE PARTS	PA97307-Y572	CUSHION-L-IMP
SPARE PARTS	PA97307-Y573	CUSHION-L-IMP
SPARE PARTS	PA97307-Y593	OUTER-BOX-L6IM
SPARE PARTS	PA97307-Y765	CUSHION-L-ADF-M
SPARE PARTS	PA97307-Y766	CUSHION-R-ADF-M
SPARE PARTS	PA97307-Y769	UPPER-SHEET
SPARE PARTS	PA97307-Y790	CUSHION-BL
SPARE PARTS	PA97307-Y791	CUSHION-BR
SPARE PARTS	PA97307-Y792	CUSHION-TL
SPARE PARTS	PA97307-Y793	CUSHION-TR
SPARE PARTS	PA97307-Y803	OUTER-BOX
SPARE PARTS	PA97307-Y806	OUTER-BOX
SPARE PARTS	PA97307-Y833	OUTER-BOX-L6A-M
SPARE PARTS	PA97307-Y857	ACC-TRAY
SPARE PARTS	PA97307-Y871	CUSHION-BL
SPARE PARTS	PA97307-Y872	CUSHION-BR
SPARE PARTS	PA97307-Y873	CUSHION-TL
SPARE PARTS	PA97307-Y874	CUSHION-TR
SPARE PARTS	PA97307-Y875	PARTITION-BOARD
SPARE PARTS	PA97307-Y895	OUTER-BOX(M10)
SPARE PARTS	PA97307-Y901	OUTER-BOX
SPARE PARTS	PA97307-Y910	COVER-SHEET
SPARE PARTS	PA97901-0911	JOINT
SPARE PARTS	PA97901-0914	JOINT
SPARE PARTS	PA97951-0086	REINFORCEMENT
SPARE PARTS	RU6ER2-S	E-RING
SPARE PARTS	RU6ER3-S	E-RING
SPARE PARTS	RU6ER6-S	E-RING
SPARE PARTS	RU6N12-121	NUT
SPARE PARTS	RU6NYBT0	NYLON BAND
SPARE PARTS	RU6NYC12	NYLON CLAMP
SPARE PARTS	RU6NYC13R5	NYLON CLAMP
SPARE PARTS	RU6SAKT4-04161	SCREW
SPARE PARTS	RU6SBD2R5-06121	SCREW
SPARE PARTS	RU6SBD3-06121	SCREW
SPARE PARTS	RU6SNA2R5-05121	SCREW
SPARE PARTS	RU6SNA2R5-06121	SCREW
SPARE PARTS	RU6SNA3-05121	SCREW
SPARE PARTS	RU6SNA3-06121	MACHINE SCREW M3X6
SPARE PARTS	RU6SPKG6-06S	SPACER
SPARE PARTS	RU6SW2N2-10121	SCREW
SPARE PARTS	RU6SW2N2-12121	SCREW
SPARE PARTS	RU6SW2N2R5-06121	SCREW
SPARE PARTS	RU6SW2N2R5-08121	SCREW

SPARE PARTS	RU6SW2N3-06115	SCREW
SPARE PARTS	RU6SW2N3-06121	SCREW
SPARE PARTS	RU6SW2N3-10121	SCREW
SPARE PARTS	RU6SW2N3-12121	SCREW
SPARE PARTS	RU6SW2N3-16121	SCREW
SPARE PARTS	RU6SW2N3-18121	SCREW
SPARE PARTS	RU6SW2N3-20121	SCREW
SPARE PARTS	RU6SW2N3-45121	SCREW
SPARE PARTS	RU6SW2N4-06121	SCREW
SPARE PARTS	RU6SW2N4-10121	SCREW
SPARE PARTS	RU6SW2N4-12121	SCREW
SPARE PARTS	RU6SW2N4-20121	SCREW
SPARE PARTS	RU6SW3N2-08121	SCREW
SPARE PARTS	RU6SW3N3-06121	SCREW
SPARE PARTS	RU6SW3N3-08121	SCREW
SPARE PARTS	RU6SW3N3-12121	SCREW(M1000)
SPARE PARTS	RU6WB3-121	WASHER
SPARE PARTS	RU6WM3-121	WASHER
SPARE PARTS	RU6WM4-121	WASHER
SPARE PARTS	RU6WM5-121	WASHER
SPARE PARTS	U120-4300-Z571	LIFTUP GEAR L
SPARE PARTS	U120-4300-Z572	LIFTUP GEAR R
SPARE PARTS	U120-4300-Z624	SCREW
SPARE PARTS	U120-4300-Z740	PICK SPRING B
SPARE PARTS	U120-4310-Z215	STOPPER
SPARE PARTS	U30L-0010-0030#M3X5	SCREW
SPARE PARTS	U30L-0010-0030#M3X8	SCREW
SPARE PARTS	U30L-0010-0043	FULCRUM SCREW
SPARE PARTS	U30L-8000-0012#4002	BEARING
SPARE PARTS	U30L-8000-0012#F3001-JOU	BEARING
SPARE PARTS	U98L-2000-0199	CKS CLAMP
SPARE PARTS	U98L-2000-0201	CKS CLAMP
SPARE PARTS	U98L-2000-0203	CKS CLAMP
SPARE PARTS	U98L-2000-0205	CKS CLAMP
SPARE PARTS	U98L-2010-0005#4.0X0.5FM	POLI SLIDER
SPARE PARTS	U98L-2010-0005#6.0X0.5FM	POLY SLIDER
SPARE PARTS	U98L-2010-0005#6.0X1.0FM	POLY SLIDER
SPARE PARTS	UO-DF04-0001	SOFTWARE,UPGRADE FOR VRS 4.X DESKTOP
SPARE PARTS	UO-WF04-0001	SOFTWARE,UPGRADE TO VRS 4.X WORKGROUP
SPARE PARTS	UP-OF01-0004	SOFTWARE,UPGRADE FOR VRS 3.X TO 4.X
SPARE PARTS	Y0AF5041	HARNESS POWER SUPPLY UNIT
SPARE PARTS	Y0AF5043	HARNESS POWER SUPPLY UNIT
SPARE PARTS	Y0BG1502	COVER LENS
SPARE PARTS	Y0BG3041	RING FOCUS BLACK
SPARE PARTS	Y0CW5044	CABLE W.A. 3P
SPARE PARTS	Y0CW5049	CABLE W.A. VG
SPARE PARTS	Y0CW5050	CABLE W.A. VG
SPARE PARTS	Y0DB5046	CABLE W.A. 3P
SPARE PARTS	Y0E71000	ASSY BOTTOM COVER WXGA
SPARE PARTS	Y0E71010	SPEAKER 15W_6
SPARE PARTS	Y0E71011	SPEAKER 15W_6
SPARE PARTS	Y0E71030	RUBBER 10W SP
SPARE PARTS	Y0E71131	RING ZOOM PC+
SPARE PARTS	Y0E71150	RUBBER KEYPAD
SPARE PARTS	Y0E71210	ASSY IOCOVER
SPARE PARTS	Y0E71300	ASSY COVER TOP WXGA US
SPARE PARTS	Y0E71301	ASSY COVER TOP WXGA EU
SPARE PARTS	Y0E72020	FAN SUNON 752
SPARE PARTS	Y0E73000	ASSY ENGINE MODULE WXGA
SPARE PARTS	Y0E73045	COVER RING FO
SPARE PARTS	Y0E75002	PCBA MAIN WXGA
SPARE PARTS	Y0E75030	ASSY POWER SUPPLY

SPARE PARTS	Y0E75040	CABLE FFC KEY
SPARE PARTS	Y0E75050	HARNESS POWER SUPPLY UNIT
SPARE PARTS	Y0E75060	CABLE LD/LAMP
SPARE PARTS	Y0E75070	AC INLET WIRE
SPARE PARTS	Y0E75080	CABLE SIGNAL HDMI
SPARE PARTS	Y0E75200	PCBA SENSOR
SPARE PARTS	Y0E75210	PCBA KEYPAD BD
SPARE PARTS	Y0E75220	PCBA LAN BD
SPARE PARTS	Y0E76020	REMOTE CONTROLLER
SPARE PARTS	Y0E76075	CABLE POWER CORD US
SPARE PARTS	Y0E76076	CABLE POWER CORD US
SPARE PARTS	Y0E76077	CABLE POWER CORD EU
SPARE PARTS	Y0E76078	CABLE POWER CORD EU
SPARE PARTS	Y0E76079	CABLE POWER CORD UK
SPARE PARTS	Y0E81000	ASSY BOTTOM COVER WUXGA
SPARE PARTS	Y0E81040	RUBBER CW UP
SPARE PARTS	Y0E81131	RING ZOOM C37
SPARE PARTS	Y0E81301	ASSY COVER TOP WUXGA EU
SPARE PARTS	Y0E81304	ASSY COVER TOP WUXGA US
SPARE PARTS	Y0E83004	ASSY ENGINE MODULE WUXGA
SPARE PARTS	Y0E85007	PCBA MAIN WUXGA
SPARE PARTS	Y3172010	DLX REAR COVER ASSY(W/OWLAN)GRY
SPARE PARTS	Y3172201	ADHESIVE TAPE COVER UP DLX
SPARE PARTS	Y3172202	ADHESIVE TAPE COVER DLX
SPARE PARTS	Y3172203	ADHESIVE TAPE COVER DOWN DLX
SPARE PARTS	Y3173100	DLX MB UT(W/OCPU,DDR,EMMC)W/OMIR
SPARE PARTS	Y3173150	DLX SWITCH/B ASSY
SPARE PARTS	Y3178520	ECBL ASSY TYPEC USB3.1(20V,1M,S0)CLK
SPARE PARTS	Y3178550	GIFT BOX ASSY FOR NON-BATT. MODEL
SPARE PARTS	Y3182010	DLX REAR COVER ASSY(W/WLAN)GRY
SPARE PARTS	Y3183100	DLX MB UT(CPU1.3G,H4G,E8G)W/MIR
SPARE PARTS	Y3183310	DLX BATTERY PACK LI
SPARE PARTS	Y3188550	GIFT BOX ASSY FOR WITH-BATT. MDL.
OPTION	PA03338-D960	SCANNER OPTION, BLACK DOCUMENT PAD
SPARE PARTS	PA03338-Y135	D LOCK PLATE L
OPTION	PA03360-0013	SCANNER OPTION, CARRIER SHEET
SPARE PARTS	PA03450-D720	PRF FRAME UNIT
SPARE PARTS	PA03450-D860	JUPITER-EH-CT3
SPARE PARTS	PA03450-D901	DRIVER PCA
SPARE PARTS	PA03450-D903	CCD UNIT
SPARE PARTS	PA03450-D910	BRAKE TORQUE UNIT
SPARE PARTS	PA03450-D923	SEPA UNIT EH
SPARE PARTS	PA03450-D956	POWER SUPPLY
SPARE PARTS	PA03450-F960	BRAKE CHECK JIG
SPARE PARTS	PA03450-K402	REV-ASSY
OPTION	PA03540-D201	SCANNER OPTION, FI-614PR
OPTION	PA03540-D801	SCANNER OPTION, BLACK DOCUMENT PAD
OPTION	PA03540-K950	SCANNER OPTION, AC CORDSET KIT
OPTION	PA03540-K951	SCANNER OPTION, AC CORDSET KIT
OPTION	PA03541-0004	SCANNER OPTION, SCANSNAP S300 SOFT CASE
OPTION	PA03575-D201	SCANNER OPTION, FI-680PRF
OPTION	PA03575-D203	SCANNER OPTION, FI-680PRB
SPARE PARTS	PA03575-D745	JUNO-CT2
OPTION	PA03610-0001	SCANNER OPTION, S1100 CASE
OPTION	PA03610-0002	SCANNER OPTION, S1100 Feed Guide
OPTION	PA03610-0007	SCANNER OPTION, S1100 Output Guide
OPTION	PA03610-0017	SCANNER OPTION, S1100i Output Guide
OPTION	PA03610-0021	SCANNER OPTION, USB CABLE
OPTION	PA03610-0051	SCANNER OPTION, USB CABLE
OPTION	PA03610-0052	SCANNER OPTION, S1100 Feed Guide
OPTION	PA03610-0057	SCANNER OPTION, S1100 Output Guide
OPTION	PA03641-0052	SCANNER OPTION, BACKGROUND PAD
OPTION	PA03670-D201	SCANNER OPTION, FI-718PR
OPTION	PA03670-D801	SCANNER OPTION, BLACK DOCUMENT PAD
OPTION	PA03670-D911	SCANNER OPTION, FI-718PR-PPM

OPTION	PA03688-0001	SCANNER OPTION, IX100 CASE
OPTION	PA03688-0002	SCANNER OPTION, IX100 Feed Guide
OPTION	PA03688-0003	SCANNER OPTION, IX100 Output Guide
OPTION	PA03688-0011	SCANNER OPTION, IX100 SOFT CASE
OPTION	PA03688-0021	SCANNER OPTION, USB CABLE
OPTION	PA03706-1001	SCANNER OPTION, ANTI-VIRUS SOFTWARE OP
OPTION	PA03706-1010	SCANNER OPTION, ANTI-VIRUS SOFTWARE OP
OPTION	PA03706-1100	SCANNER OPTION, ANTI-VIRUS SOFTWARE OP
OPTION	PA03708-K991	SCANNER OPTION, UK PLUG(50PCS)
OPTION	PA03708-K992	SCANNER OPTION, AUS PLUG(50PCS)
OPTION	PA03708-K993	SCANNER OPTION, KOR PLUG(50PCS)
OPTION	PA03708-K994	SCANNER OPTION, ARG PLUG(50PCS)
OPTION	PA03708-K995	SCANNER OPTION, USA PLUG(50PCS)
OPTION	PA03710-D401	SCANNER OPTION,fi-748PRB
OPTION	PA03740-D101	SCANNER OPTION, FI-760PRB
OPTION	PA03740-D801	SCANNER OPTION, FI-760PRB-PPM
OPTION	PA03770-0015	Photo Carrier Sheet
OPTION	PA03795-0018	SCANNER OPTION, Booklet Carrier Sheets
OPTION	PA03805-0002	SCANNER OPTION, Soft Case
OPTION	PA03810-0020	SCANNER OPTION, Booklet Carrier Sheets
OPTION	PA03810-D201	SCANNER OPTION, fi-819PRB
OPTION	PA03810-D301	SCANNER OPTION, BLACK DOCUMENT PAD
OPTION	PA03950-0409	SCANNER OPTION, SCANSNAP BAG BULK(20pcs)
OPTION	PA03951-0651	SCANNER OPTION, SCANSNAP BAG
SOFTWARE	PA43201-2509	PaperStream Capture for SP Series B/L
SOFTWARE	PA43201-2510	PaperStream Capture for SP Series O/L
OPTION	PA43402-C22901	SCANNER OPTION,IMAGE PROCESSING SOFTWARE
OPTION	PA43404-A283	SOFTWARE,SCANDALL PRO V2 PREM UPGRADE OP
OPTION	PA43404-A433	OPTION, 2D BARCODE FOR PAPERSTREAM
OPTION	PA43404-A702	SOFTWARE,SCANDALL PRO V2 PREM SETUP DVD
OPTION	PA43404-A704	SOFTWARE,SCANDALL PRO V2 SETUP DVD
OPTION	PA43404-A868	PaperStream Capture for SP Series Disc